



CiscoNCS540RouterHardwareInstallationGuide

FirstPublished:2018-03-28

LastModified:2026-07-14

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicates of soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2018–2025 Cisco Systems, Inc. All rights reserved.



CONTENTS

CHAPTER1

SafetyWarni	1
StandardWarningStatements	1
Safetyguidelinesforpersonalsafetyandequipmentpr	3
Safetyprecautionsformoduleinstallationandr	3
Safetywithelectricity	4
Power supply considerations	6
PowerConnectionGuidelines	7
GuidelinesforDC-PoweredSystems	7
GuidelinesforAC-PoweredSystems	7
PreventPowerLoss	7
PreventingESDdamage	8

CHAPTER2

CiscoNCS540RouterOver	9
NetworkInterfaces	10
Specification	12
InterfaceNaming	12
PortSpeedon25GPorts	15
NetworkTimingInterfaces	16
GNSS	16
GNSSModuleRFInputRequirements	16
ExternalAlarmInputs	17
Console	18
USBConsole	18
OnlineInsertionandRemoval	18
GracefulShutdownofDCPSU	18
SupportedTransceiverModules	19

CHAPTER 3

Prepare for Installation	21
General Precautions	21
Site Planning Checklist	22
Environmental Requirements	22
Airflow Guidelines	22
Site Power Guidelines	25
Electrical Circuit Requirements	26
Site Cabling Guidelines	27
Asynchronous Terminal Connections	27
Interference Considerations	27
Tools and Equipment	28
Prepare Your Location	28
Prepare Yourself	29
Prepare Rack for Router Installation	30
Cabinet Selection Guidelines	30
Unpack the Cisco NCS540 Router	31

CHAPTER 4

Install the Device	37
Rack Compatibility	37
Rack Types	38
Setup Device on Rack or Wall	40
Rack-Mount	40
Wall Mount	50
Install Wall Brackets	50
Wall Mount the Device	53
Installing the Air Filter	54
Install the air filter (N540-FR-KIT-EG)	56
Install the air filter (N540-FR-KT-EG-200)	62
Ground the Device	69
Install the AC Power Cables	69
Activate an AC Power Supply Module	70
Install the DC Power Cables	71
Activate a DC Power Supply Module	73

PortConnectionGuidelines	74
ConnecttotheConsolePort	74
ConnecttotheManagementEtherne	76
ConnectingTimingCables	77
ConnectingaCabletotheBITSInterfa	78
ConnectingCablestoGPSInterface	78
ConnectingaCabletotheInput10MHzor1PPSInterf	78
ConnectingaCabletotheOutput10MHzor1PPSInt	79
ConnectingaCabletotheToDInterface	79
ConnectingaCabletotheGNSSAntennaInte	79
InstallandRemoveTransceiverMo	80
InstallandRemoveSFPModules	80
BaleClaspSFPorSFP+Module	81
InstallaBaleClaspSFPorSFP+Module	81
RemoveaBaleClaspSFPorSFP+Module	82
InstallandRemoveQSFPTransceiverMod	84
Overview	84
RequiredToolsandEquipment	85
Installthe100-GigabitTransceiverModule	85
AttachtheOpticalNetworkCable	87
Removethe100-	88
ConnectInterfacePorts	89
ConnectaFiber-	89
DisconnectOpticalPortsfromtheNet	90
MaintainTransceiversandOpticalCa	90
bles	

CHAPTER5

ConfiguretheDe	91
CreatetheInitialRouterConfigura	91
VerifyDeviceInstallation	93

CHAPTER6

ReplaceFanModuleandPowerS	95
ReplaceFanModule	95
ReplacePowerSupply	96
RemovetheDCPowerSupplyModule	97

InstalltheDCPowerSupplyModule	98
RemovetheACPowerSupplyMod	99
InstalltheACPowerSupplyModule	100

APPENDIX A

Appendix	101
LEDs	101
RouterLEDs	101
FanAssemblyLEDs	103
PowerSupplyLEDs	104
FanAssemblyandPowerSupplyLEDCombina	106
SystemSpecifications	107
WeightandPowerConsumption	107
EnvironmentalSpecifications	107
Thermallimitations	107
EMCcompliance	109
TransceiverandCableSpecifications	110
RJ-45Connectors	110
GPSPortPinouts	110
Time-of-DayPortPinouts	111
BITSInterface	111
ManagementandPTPEthernetPortPin	112
USBPortPinouts	112
AlarmPortPinouts	113
ConsolePortPinouts	115
ACPowerCordSpecifications	116



CHAPTER 1

Safety Warnings

This handout lists the safety warnings necessary for handling this chassis. Before you install or service the chassis, review these safety warnings to avoid injuring yourself or damaging the equipment.

For a complete list of translated safety warnings, see the [Regulatory Compliance and Safety Information—Cisco NCS500 Series Routers document](#).

The safety warnings are grouped under the following sections:

- [Standard Warning Statements, on page 1](#)
- [Safety guidelines for personal safety and equipment protection, on page 3](#)
- [Safety precautions for module installation and removal, on page 3](#)
- [Safety with electricity, on page 4](#)
- [Power supply considerations, on page 6](#)
- [Preventing ESD damage, on page 8](#)

Standard Warning Statements



Note **Statement 407**—Japanese Safety Instruction

You are strongly advised to read the safety instruction before using the product.

<https://www.cisco.com/web/JP/techdoc/pldoc/pldoc.html>

When installing the product, use the provided or designated connection cables/power cables/AC adapters.

〈 品使用における安全上の注意〉

www.cisco.com/web/JP/techdoc/index.html

接続ケーブル、 源コードセット、 **ACアダプタ**、 バッテリなどの部品は、必ず添付品または指定品をご使用ください。添付品・指定品以外をご使用になると故障や 作不良、火災の原因となります。また、 源コードセットは弊社が指定する 品以外の 気 器には使用できないためご注意ください。

**Warning Statement1003—DC Power Disconnection**

To reduce risk of electric shock or personal injury, disconnect DC power before removing or replacing components or performing upgrades.

**Warning Statement1006—Chassis Warning for Rack-Mounting and Servicing**

To prevent bodily injury when mounting or servicing this unit in a rack, you must take special precautions to

ensure that the system remains stable. The following guidelines are provided to ensure your safety: • This unit should be mounted at the bottom of the rack if it is the only unit in the rack.

- When mounting this unit in a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.

- If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack.

**Warning Statement1022—Disconnect Device**

To reduce the risk of electric shock and fire, a readily accessible disconnect device must be incorporated in the fixed wiring.

**Warning Statement1024—Ground Conductor**

This equipment must be grounded. To reduce the risk of electric shock, never defeat the ground conductor or

operate the equipment in the absence of a suitably installed ground conductor. Contact the appropriate electrical inspection authority or an electrician if you are uncertain that suitable grounding is available.

**Warning Statement1049—Rack Installation**

To reduce the risk of bodily injury, mount the chassis on a rack that is permanently affixed to the building.

**Warning Statement9001—Product Disposal**

The ultimate disposal of this product should be handled according to all national laws and regulations.

**Warning Statement1017—Restricted Area**

This unit is intended for installation in restricted access areas. Only skilled, instructed, or qualified personnel can access a restricted access area.



Warning

Statement1071—WarningDefinition**IMPORTANTSAFETYINSTRUCTIONS**

Beforeyouworkonanyequipment,beawareofthehazardsinvolvedwithelectricalcircuitryandbefamiliar withstandardpracticesforpreventingaccidents.Readtheinstallationinstructionsbeforeusing,installing,or connectingthesystemtothepowersource.Usethestatementnumberatthebeginningofeach warning statementtolocateitstranslationinthetranslatedsafetywarningsforthisdevice.

SAVETHESEINSTRUCTIONS

Safetyguidelinesforpersonalsafetyandequipmentprotection

Thefollowingguidelinesensureyoursafetyandprotecttheequipment.Thislistdoesnotincludeallthe potentiallyhazardoussituations.Therefore,youmustbealert.

- Beforemovingthesystem,alwaysdisconnectallpowercordsandinterfacecables.
- Neverassumethatpowerisdisconnectedfromacircuit;alwayscheck.
- Beforeandafterinstallation,keepthechassisareacleananddustfree.
- Keptoolsandassemblycomponentsawayfromwalkareaswhereyouorotherscantrip overthem.
- Donotworkaloneifpotentiallyhazardousconditionsexist.
- Donotperformanyactionthatcreatesapotentialhazardtopeopleormakestheequipment unsafe.
- Donotwearlooseclothingthatmaygetcaughtinthechassis.
- Whenworkingunderconditionsthatmaybehazardoustoyoureyes,wearsafetyglasses.

Safetyprecautionsformoduleinstallationandremoval

Besuretoobservethefollowingsafetyprecautionswhenyouworkonthechassis.



Warning

Statement1006—ChassisWarningforRack-MountingandServicing

To prevent bodily injury when mounting or servicing this unit in a rack, you must take special precautions to

ensure that the system remains stable. The following guidelines are provided to ensure your safety: • This unit should be mounted at the bottom of the rack if it is the only unit in the rack.

- When mounting this unit in a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.

- If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack.



Warning

Statement1008—Class1LaserProduct

This product is a Class 1 laser product.



Warning

Statement1089—InstructedandSkilledPersonDefinitions

An instructed person is someone who has been instructed and trained by a skilled person and takes the necessary precautions when working with the equipment.

A skilled person or qualified personnel is someone who has training or experience in the equipment technology and understands potential hazards when working with the equipment.

There are no serviceable parts inside. To avoid risk of electric shock, do not open.



Warning

Statement1090—InstallationbySkilledPerson

Only a skilled person should be allowed to install, replace, or service this equipment. See statement 1089 for the definition of a skilled person.

There are no serviceable parts inside. To avoid risk of electric shock, do not open.

Safetywithelectricity



Warning

Statement1003—DCPowerDisconnection

To reduce risk of electric shock or personal injury, disconnect DC power before removing or replacing components or performing upgrades.



Warning

Statement1022—DisconnectDevice

To reduce the risk of electric shock and fire, a readily accessible disconnect device must be incorporated in the fixed wiring.



Warning

Statement1024—GroundConductor


This equipment must be grounded. To reduce the risk of electric shock, never defeat the ground conductor or operate the equipment in the absence of a suitably installed ground conductor. Contact the appropriate electrical inspection authority or an electrician if you are uncertain that suitable grounding is available.



Warning

Statement1028—MoreThanOnePowerSupply

This unit might have more than one power supply connection. To reduce risk of electric shock, remove all connectionstode-energizetheunit.



Warning

Statement1046—InstallingorReplacingtheUnit

To reduce risk of electric shock, when installing or replacing the unit, the ground connection must always be made first and disconnected last.

If your unit has modules, secure them with the provided screws.



Warning

Statement2004—GroundedEquipment

This equipment is intended to be grounded to comply with emission and immunity requirements. Ensure that the switch functional ground lug is connected to earth ground during normal use.



Warning

Statement1073—NoUser-ServiceableParts

There are no serviceable parts inside. To avoid risk of electric shock, do not open.



Warning

Statement1074—ComplywithLocalandNationalElectricalCodes

To reduceriskofelectricshockorfire,installationoftheequipmentmustcomplywithlocaland national electricalcodes.

Whenworkingonequipmentthat ispoweredbyelectricity,followtheseguidelines:

- Locatetheroom'semergencypower-offswitch.Ifanelectricalaccidentoccurs,youknowwheretoturnoffthepower.
- Beforestartingworkonthesystem,turnofftheDCmaincircuitbreakeranddisconnectthepower terminalblockcable.
- Disconnectallpowerwhen:
 - Workingonornearpowersupplies
 - Installingorremovingadevicechassisornetworkprocessormodule
 - Performingmosthardwareupgrades
- Neverinstallequipmentthatappearsdamaged.
- Carefullyexamineyourworkareaforpossiblehazards,suchasmoistfloors,ungroundedpowerextension cables,andmissingsafetygrounds.
- Neverassumethatpowerisdisconnectedfromacircuit;alwayscheck.
- Neverperformanyactionthatcreatesapotentialhazardtopeopleormakestheequipmentunsafe. • Ifanelectricalaccidentoccursandyouareuninjured:
 - Usecautiontoavoidinjuringyourself.
 - Turnoffpowertothedevic.
 - Seekmedicalattention,ifnecessary.

Usethefollowingguidelineswhenworkingwithanyequipmentthat isdisconnectedfromapowersource, butconnectedtotelephonewiringornetworkcabling:

- Wheninstallingormodifyingtelephonelines,usecaution.
- Neverinstalltelephonejacksinwetlocationsunless thejackisdesignedtohandlesuch locations. • Neverinstalltelephonewiringduringalightningstorm.

Powersupplyconsiderations

Checkthepowerat yoursitetoensurethatyouarereceivingcleanpower(freeofspikesandnoise).If necessary,installapowerconditioner.

PowerConnectionGuidelines

This section provides guidelines for connecting the device power supplies to the site power source.



Warning **Statement1024**—Ground Conductor

This equipment must be grounded. To reduce the risk of electric shock, never defeat the ground conductor or operate the equipment in the absence of a suitably installed ground conductor. Contact the appropriate electrical inspection authority or an electrician if you are uncertain that suitable grounding is available.

Guidelines for DC-Powered Systems

Basic guidelines for DC-powered systems include the following:

- Each chassis power supply has its own dedicated input power source. The source must comply with the safety extra-low voltage (SELV) requirements in the UL60950-1, UL62368-1, CSA60950-1, CSA 62368-1, EN60950-1, EN62368-1, IEC60950-1, and IEC62368-1 standards.
- Protect the circuit by a dedicated two-pole DC circuit breaker. Ensure that the circuit breaker is sized according to the power supply input rating and local or national code requirements.
- The circuit breaker is considered as the disconnect device and is easily accessible.
- The system ground is the power supply and chassis ground.
- Use the grounding lug to attach a wrist strap for ESD protection during servicing.
- Do not connect the DC return wire to the system frame or to the system-grounding equipment.
- Ensure that the DC return is grounded at the source side.
- Ensure that each power feed of the equipment is connected to different power sources.

Guidelines for AC-Powered Systems

Basic guidelines for AC-powered systems include the following:

- Each chassis power supply has its own dedicated branch circuit.
- Ensure that the circuit breaker is sized according to the power supply input rating and local or national code requirements.
- The AC power receptacles that are used to plug in the chassis must be the grounding type. The grounding

conductor that connects to the receptacles must connect to protective earth ground at the service equipment.

Prevent Power Loss

Use the following guidelines to prevent power loss to the device:

- To prevent input power loss, ensure that the maximum load on each circuit supplying the power is within the current ratings of the wiring and breakers.

- In some systems, you can use an UPS to protect against power failures at your site. Avoid UPS types that use ferroresonant technology. These UPS types can become unstable with systems such as the device, which can have substantial current-draw fluctuations due to bursty data traffic patterns.


Determining power requirements is useful for planning the power distribution system to support the device.

PreventingESDdamage

Electrostatic Discharge (ESD) can damage equipment and impair electrical circuitry. ESD may occur when electronic printed circuit cards are improperly handled and can cause complete or intermittent failures. When removing and replacing modules, always follow these ESD prevention procedures:

- Ensure that the device chassis is electrically connected to earth ground.
- Wear an ESD-preventive wrist strap, ensuring that it makes good skin contact. To channel unwanted ESD voltages safely to ground, connect the clip to an unpainted surface of the chassis frame. To guard against ESD damage and shocks, the wrist strap and cord must operate effectively.
- If no wrist strap is available, ground yourself by touching a metal part of the chassis.
- When installing a component, use any available ejector levers or captive installation screws to properly seat the bus connectors in the backplane or midplane. These devices prevent accidental removal, provide proper grounding for the system, and help to ensure that bus connectors are properly seated.
- When removing a component, use an available ejector lever or captive installation screws, if any, to release the bus connectors from the backplane or midplane.
- Handle components by only their handles or edges; do not touch the printed circuit boards or connectors.
 - Place a removed component board side up on an antistatic surface or in an antistatic-shielding container. If you plan to return the component to the factory, immediately place it in an antistatic-shielding container.
- Avoid contact between the printed circuit boards and clothing. The wrist strap only protects components from ESD voltages on the body; ESD voltages on clothing can still cause damage.
- Never attempt to remove the printed circuit board from the metal carrier.

For the safety of your equipment, periodically check the resistance value of the antistatic wrist strap. Maintain the value between 1 and 10 MΩ.



CHAPTER 2

Cisco NCS540 Router Overview

The Cisco NCS540 1RU router complements Cisco's offerings for IP-RAN solutions for the GSM, UMTS, LTE, and CDMA.

The Cisco NCS540 includes the following variants.

Table 1: Cisco NCS540 Variants

Variant	Conformal Coating
N540-24Z8Q2C-SYS	No
N540X-ACC-SYS	Yes ¹
N540-ACC-SYS	No
N540-28Z4C-SYS-A N540-28Z4C-SYS-D	No
N540-12Z20G-SYS-A N540-12Z20G-SYS-D	No
N540X-12Z16G-SYS-A N540X-12Z16G-SYS-D	Yes
N540X-16Z4G8Q2C-A N540X-16Z4G8Q2C-D	Yes

¹The printed circuit boards are conformal coated to provide enhanced protection against moisture, dust, and corrosive gases. For additional information and deployment conditions, we recommend you to contact our Cisco support team.



Note The Cisco N540-24Z8Q2C-SYS, N540X-ACC-SYS, N540-ACC-SYS, N540-28Z4C-SYS, N540-12Z20G-SYS-A/D, N540X-12Z16G-SYS-A/D and N540X-16Z4G8Q2C-A/D are collectively referred to as the Cisco NCS540 Router in this document. Any differences between the routers are specifically called out.

For more information on its features and benefits, see the [Cisco Network Convergence System 540 Router Data Sheet](#).


- [Network Interfaces, on page 10](#)
- [Specification, on page 12](#)
- [Interface Naming, on page 12](#)
- [Port Speed on 25G Ports, on page 15](#)
- [Network Timing Interfaces, on page 16](#)
- [GNSS, on page 16](#)
- [External Alarm Inputs, on page 17](#)
- [Console, on page 18](#)
- [Online Insertion and Removal, on page 18](#)
- [Graceful Shutdown of DCPSU, on page 18](#)
- [Supported Transceiver Modules, on page 19](#)

Network Interfaces

The Cisco NCS540 1RU Router has the following hardware features:

- 24x10G SFP+ Ports
 - Support DWDM & ZR Optics
- 8x25G SFP+ Ports
- 2x100G QSFP28 Ports

Figure 1: Cisco N540-ACC-SYS



Note All ports are color-coded in the chassis for ease of access; for example, the 10G SFP+ Ports are in blue, the 25G SFP+ Ports are in yellow, and the 100G QSFP28 Ports are in green.

The Cisco N540-28Z4C-SYS-A/D1RU Router has the following hardware features:

- 28x1G/10G SFP+ Ports
- 4x100G QSFP28 Ports with Non-MACsec

Figure 2: Cisco N540-28Z4C-SYS-A





Figure3:CiscoN540-28Z4C-SYS-D



TheCiscoN540-12Z20G-SYS-A/

D1RURouterhasthefollowinghardwarefeatures:

- 20x1GSFP+Ports
- 12x1G/10GSFP+Ports

Figure4:CiscoN540-12Z20G-SYS-A



Figure5:CiscoN540-12Z20G-SYS-D



TheCiscoN540X-12Z16G-SYS-A/

D1RURouterhasthefollowinghardwarefeatures:

- 12x1GSFP+Ports
- 12x10G/1GSFP+Ports
- 4x1GCopperPorts

Figure6:CiscoN540X-12Z16G-SYS-A





Figure7:CiscoN540X-12Z16G-SYS-D



TheCiscoN540X-16Z4G8Q2C-A/

D1RURouterhasthefollowinghardwarefeatures:

- 4x1GCopperPorts
- 16x1G/10GSFP+Ports
- 8x10G/25GSFP+Ports
- 2x100GQSFP+Ports

Figure8: CiscoN540X-16Z4G8Q2C-A






Figure9: CiscoN540X-16Z4G8Q2C-D



The CiscoN540X-16Z8Q2C-D router has the copper ports (0 to 3) removed. The router has the following hardware features:

- 16x1G/10GSFP+ Ports
- 8x10G/25GSFP+ Ports
- 2x100GQSFP Ports

Figure10: CiscoN540X-16Z8Q2C-D



Specification

For information on physical specification, temperature, Route Processor, and other details for all variants, see [CiscoNCS540 chassis specification](#) in the [Cisco Network Convergence System 540 Router Data Sheet](#).

Interface Naming

The following table shows the interface naming of the CiscoN540-24Z8Q2C-SYS, N540X-ACC-SYS, and N540-ACC-SYS variants:

Table2: Port Numbering

1G/10G Dual rate ports (SFP+)			1G/10G/25G Dual rate ports (SFP28)			40G/100G ports (QSFP28)
0/0	to	22	24	to	30	1/0
1		23	25		0/31	1/1

The interface path is `rack/slot/module/port`. The slash between values is required as part of the notation.

- **GigE**—0/0/0/0-0/0/0/31

- **TenGigE**—0/0/0/0-0/0/0/31
- **TwentyFiveGigE**—0/0/0/24-0/0/0/31
- **FortyGigE**—0/0/1/0-0/0/1/1
- **HundredGigE**—0/0/1/0-0/0/1/1



Note Dual-Rate functionality is supported only with the Supported SFP.

Table 3: Maximum Number of Interfaces

Category	Maximum Interface	Port Number
100ME copper	24	0/0-23
1GE	32	0/0-31
10GE	32/40* ²	0/0-31, 1/0-1*
25GE	8/16*	0/24-31, 1/0-1*
40GE	2	1/0-1
100GE	2	1/0-1

²*4x10GE or 4x25GE option

The following tables show the interface naming of the Cisco N540-28Z4C-SYS-A/D, N540-12Z20G-SYS-A/D, N540X-12Z16G-SYS-A/D, N540X-16Z4G8Q2C-A/D, and N540X-16Z8Q2C-D variants:

Table 4: Port Numbering of Cisco N540-28Z4C-SYS-A/D

1G/10G Dual-rate ports (SFP+)	100G ports (QSFP28)
0/0 to 0/27	0/28 to 0/31

- **GigE**—0/0/0/0-0/0/0/27
- **TenGigE**—0/0/0/0-0/0/0/27
- **HundredGigE**—0/0/0/28-0/0/0/31

Table5:PortNumberingofCiscoN540X-12Z16G-SYS-A/D

1GCopper ports	1Gports (SFP)	10Gports (SFP+)
0/0 to 0/3	0/4 to 0/15	0/16 to 0/27

•**GigE**—0/0/0/4-0/0/0/15

•**TenGigE**—0/0/0/16-0/0/0/27

Table6:PortNumberingofCiscoN540-12Z20G-SYS-A/D

1Gports (SFP)	1G/10GDualrateports (SFP+)
0/0 to 0/31	0/20 to 0/31

•**GigE**—0/0/0/0-0/0/0/31

•**TenGigE**—0/0/0/20-0/0/0/31

Table7:PortNumberingofCiscoN540X-16Z4G8Q2C-A/D

1GCopper ports	1G/10GDualrateports (SFP+)	1G/10G/ 25GDualrateports(SFP28)	100Gports (QSFP28)
0/0 to 0/3	0/4 to 0/19	0/20 to 0/27	0/28 and 0/29

•**GigE**—0/0/0/4-0/0/0/27

•**TenGigE**—0/0/0/20-0/0/0/27

•**TwentyFiveGigE**—0/0/0/20-0/0/0/27

•**HundredGigE**—0/0/0/28-0/0/0/29

Table8:PortNumberingofCiscoN540X-16Z8Q2C-D

1G/10GDualrateports (SFP+)	1G/10G/ 25GDualrateports(SFP28)	100Gports (QSFP28)
0/4 to 0/19	0/20 to 0/27	0/28 and 0/29

- **GigE**—0/0/0/4-0/0/0/27
- **TenGigE**—0/0/0/20-0/0/0/27
- **TwentyFiveGigE**—0/0/0/20-0/0/0/27
- **HundredGigE**—0/0/0/28-0/0/0/29

PortSpeedon25GPorts

The25Gportsaredividedintofourquads(0-

3).Eachquadhousesthefollowingports: •Quad0-Ports24-27

- Quad1-Ports28-31
- Quad2-Ports32-35
- Quad3-Ports36-39

LimitationsandImportantGuidelines

- 25Gisthedefaultmodesetonthequad.
- 1Gand10Gcannotcoexistonthesamequadas25G.
- 10Gmodesupportsboth1Gand10G.

Toconfigurethe25Gquadportsinto10Gports,usethefollowingcommand:

```
RP/0/RP0/CPU0:router(config)#hw-modulequadXlocation0/0/CPU0
```

```
RP/0/RP0/CPU0:router(config-quad-0x0)#mode10g
```

Xisthenumberofquads(0,1,2,3...n)supported.Eachquadhasadefaultspeedof25G.Youcanconfigure theportin10Gorrevertto25Gusingnoformofthecommand:

```
RP/0/RP0/CPU0:router(config)#nohw-modulequadXlocation0/0/CPU0mode10g
```



Note Aquadnumberalwaysstartsfrom0tothemaximumsupportednumber.Thenumberofqua supportedvariesfromplatformtoplatformandtheCLIvalidatesit.Forexample,theNCS540S eriesRouter supportstwoquads(0and1).IfyouenterX=3,theCLIreturnsanerror.

Afteryouconfiguretheport-modespeed,youcanconfigurethe100GEinterface:

- 100G—Each optics controller configuration creates a single 100GE port:

- **interface HundredGigE** *r/s/i/p/0* (where *p* = CTP2 port 0-5)

- 0/3/0/0/0

- 0/3/0/1/0

- 0/3/0/2/0

- 0/3/0/3/0

- 0/3/0/4/0

- 0/3/0/5/0

Network Timing Interfaces

- BITS input or output—
The BITS interface supports clock recovery from either a T1 at 1.544 MHz or an E1 at 2.048 MHz, configurable by software. BITS interface is provided through a standard RJ-48 connector on the front panel.
- 1PPS input or output and ToD input or output—This shielded RJ-45 interface is used for input or output of time-of-day (ToD) and 1PPS pulses. ToD format includes both NTP and IEEE 1588-2008 time formats.

The same RS422 pins for 1PPS and ToD are shared between input and output directions. The direction for each can be independently configurable through software.

Use an SMB connector on the front panel for the following:

- GPS 10 MHz input and output—10 MHz input for GPS synchronization.
- GPS 1 PPS input and output—1 PPS input for GPS synchronization.

GNSS

GNSS module has an in-built ESD protection on all pins, including the RF-input pin. However, additional

surge protection is required if an outdoor antenna is to be connected. The Lightning Protector must support a low clamping voltage (less than 600V).

A lightning protection must be mounted at the place where the antenna cable enters the building. The primary

lightning protection must be capable of conducting all potentially dangerous electrical energy to Protective Earth (PE).

Surge arrestor must support DC-

pass and suitable for the GPS frequency range (1.575 GHz) with low attenuation.

GNSS Module RF Input Requirements

- For optimal performance, the GNSS module requires an active GPS/GNSS antenna with built-in Low-Noise Amplifier (LNA). The antenna LNA amplifies the received satellite signals for two purposes:
 - Compensation of losses on the cable

- Lifting the signal amplitude to the suitable range for the receiver frontend

The Amplification required is $22\text{ dB gain} + \text{cable/connector loss} + \text{Splitter signal loss}$.

The recommended range of LNA gain (minus all cable and connector losses) at the connector of the

receiver module is 22 dB to 30 dB with a minimum of 20 dB and a maximum of 35 dB .

- GNSS module provides 5 V to the active antenna through the same RF input.
- Surge requirement:
 - GNSS modules have built-in ESD protection on all pins, including the RF input pin. However, additional surge protection may be required if rooftop antennas are to be connected, to meet the regulations and standards for lightning protection of countries where the end-product is installed.
 - Lightning protection must be mounted at the place where the antenna cable enters the building. The primary lightning protection must be capable of conducting all potentially dangerous electrical energy to PE.
 - Surge arrestors should support DC-pass and suitable for the GPS frequency range (1.575 GHz) with low attenuation.

• Antenna Sky visibility:

- GPS signals can only be received on a direct line of sight between antenna and satellite. The antenna must have a clear view of the sky. For proper timing, minimum of four satellites should be locked.



Note The antenna terminal should be earthed at the building entrance in accordance with the ANSI/NFPA 70, the National Electrical Code (NEC), in particular Section 820.93, Grounding of Outer Conductive Shield of a Coaxial Cable.

- Use a passive splitter if more than one GNSS module is fed from a single antenna.



Note The splitters should have all the RF ports capable of DC-module.

External Alarm Inputs

The router supports four dry contact alarm inputs through an RJ-45 jack at the rear panel.

- Normally Open— indicates that no current flows through the alarm circuit and the alarm is generated when the current is flowing.

Each alarm input can be provisioned as critical, major, or minor.

Console

The RS232 console port provides transmission (Tx), reception (Rx), and ground (Gnd).

USB Console

A single USB 2.0 Type-A receptacle on the front panel of the router provides console access to ROMMON, Cisco IOS-XR, and diagnostics. While it uses the Type-A connector, it operates as a USB peripheral only for connection to an external host computer. This interface requires the use of a Type-A to Type-A connector instead of a standard USB cable.



Note Use of the USB console is mutually exclusive of the RS232 console port. This interface requires a Type-A to Type-A USB cable.

Online Insertion and Removal

The router supports the following Online Insertion and Removal (OIR) operations:

- When an SFP is removed, there is no effect on traffic flowing on other ports.
- When an SFP is installed, the system initializes that port for operation based on the current configuration. If the inserted SFP is incompatible with the current configuration of that port, the port does not become operational until the configuration is updated.
- When both power supplies are installed and active, the load may be shared between them or a single PSU supports the whole load. When a power supply is not working or the input cable is removed, the remaining power supply takes the entire load without disruption.

Graceful Shutdown of DC PSU

If the DC input power to the DC PSU falls below 37V, graceful shutdown of the power supply is initiated, and the chassis is shutdown. To power up the chassis again, shut off the DC circuit at the circuit breaker, then turn on the DC circuit. The chassis will power up if the DC input power is above 41V to 54V.

Graceful shutdown is supported only on the following NCS540 routers:

- N540-24Z8Q2C-SYS
- N540X-ACC-SYS
- N540-ACC-SYS



Note You can disable the graceful shutdown of the DCPSU using the **environment graceful-** command in Admin Configuration mode. When graceful shutdown is disabled, the chassis will shutdown if the DC input power falls below 37V +/- 1V. The chassis will recover (power on again) if the DC input power to the DCPSU is above 37V to 54V. In this mode, the long-term reliability of the router can be impacted if the DC input power continues to fluctuate between 30V and 54V (resulting in continuous power-on and power-off cycles).

Supported Transceiver Modules

For more information on the supported transceiver modules, see [Transceiver Module Group \(TMG\) Compatibility Matrix](#). In the **Begin your Search** search box, enter the keyword NCS540 and click **Enter**.



CHAPTER 3

Prepare for Installation

Before you install the Cisco NCS540, you must prepare your site for the installation.

Preparing your site involves these tasks:

- [General Precautions, on page 21](#)
- [Site Planning Checklist, on page 22](#)
- [Environmental Requirements, on page 22](#)
- [Airflow Guidelines, on page 22](#)
- [Site Power Guidelines, on page 25](#)
- [Site Cabling Guidelines, on page 27](#)
- [Tools and Equipment, on page 28](#)
- [Prepare Your Location, on page 28](#)
- [Prepare Yourself, on page 29](#)
- [Prepare Rack for Router Installation, on page 30](#)
- [Cabinet Selection Guidelines, on page 30](#)
- [Unpack the Cisco NCS540 Router, on page 31](#)

General Precautions

Observe the following general precautions when using and working with your chassis:

- Keep your system components away from radiators and heat sources, and do not block cooling vents.
- Do not spill food or liquid on your system components, and never operate the product in a wet environment.
- Do not push any objects into the openings of your system components. Doing so can cause fire or electric shock by shorting out interior components.
- Position system cables and power supply cable carefully. Route system cables and the power supply cable and plug so that they are not stepped on or tripped over. Ensure that nothing is resting on your system component cables or power cable.
- Do not modify power cables or plugs. Consult a licensed electrician or your power company for site modifications. Always follow your local and national wiring rules.
- If you turn off your system to avoid damage to the system components, wait at least 30 seconds before turning it on again.

SitePlanningChecklist

Use the following checklist to carry out all site planning tasks:

- The site meets environmental requirements.
- The site's air conditioning system can compensate for the heat dissipation of the chassis.
- The floor space that the chassis occupies can support the weight of the system.
- Electrical service to the site complies with the safety with electricity requirements.
- The electrical circuit servicing the chassis complies with the power supply requirements.
- Console port wiring and cabling limitations have been considered in accordance to TIA/EIA-232F.
- The chassis Ethernet cabling distances are within prescribed limits.
- The equipment rack where the chassis is to be installed complies with prescribed requirements.
- The following factors have been carefully considered when selecting rack: location, safety, ease of maintenance, and proper airflow.

Environmental Requirements



Note The outside plant installation is not supported on Cisco N540-28Z4C-SYS-A/D, and N540-routers.

For outside plant installation (cell site cabinet, hut, and so on), you must protect the router against airborne contaminants, dust, moisture, insects, pests, corrosive gases, polluted air, or other reactive elements. Sealed equipment chamber with air-conditioning or a heat exchanger is recommended for OSP deployments. The equipment chamber must comply with the temperature and clearance requirements. To achieve this level of protection, we recommend that the unit be installed in a fully sealed enclosure or cabinet. Examples of such cabinets include IP65 cabinets with heat exchanger complying with Telcordia GR487. Temperature must be maintained within -40°C to 70°C.

For more information on Environmental properties and Regulatory standards, see the [Cisco Network Convergence System 540 Router Data Sheet](#).

Airflow Guidelines

Cool air is circulated through the router by fans that are located along the back side of the router. The internal fans maintain acceptable operating temperatures for the internal components by drawing in cool air through the vents, and circulating the air through the router.

To ensure adequate airflow, it is recommended that you maintain a minimum clearance distance always, as mentioned in the following figure.

- Front clearance—5 inches (12.7 centimeters)

- Rear clearance—2 inches (5.08 centimeters)

Figure 11: Top View of Clearance




Figure 12: Side View of Clearance




Figure13:AirflowSideView




Table9:AirflowGuidelines

Router	Flow Direction	Air Clearance
N540X-16Z4G8Q2C-A N540X-16Z4G8Q2C-D N540X-12Z16G-	Right to Left	At least 3 inches (7.62 centimeters) required on both inlet and exit directions.

Note the following points:

- When installing the router in a back-to-back position with another device, ensure that there is a minimum of 3.9 inches (10 centimeters) airflow clearance between the two devices.
- If airflow through the equipment track and the router that occupy it is blocked or restricted, or if the ambient air being drawn into the rack is too warm, an overtemperature condition may occur within the rack and the router that occupy it.
- The site must be as dust-free as possible. Dust tends to clog the router fans, reducing the flow of cooling air through the equipment track and the router that occupy it, thus increasing the risk of an overtemperature condition.
- Enclosed racks must have adequate ventilation. Ensure that the rack is not congested because each router generates heat. An enclosed rack must have louvered sides and a fan top to provide cooling air. The equipment generates heat near the bottom of the rack, which can be drawn upward into the intake ports of the equipment above.

- When mounting a router in an open rack, ensure that the rack frame does not block the exhaust fans.
- When rack-installed equipment fails, especially equipment in an enclosed rack, try operating the equipment by itself, if possible. Power off all the other equipment in the rack (and in adjacent racks) to give the router maximum cooling air and clean power.
- Avoid installing the router in a location in which the router air intake vents may draw in the exhaust air from adjacent equipment. Consider how the air flows through the router; the air flow direction is front to back, with ambient air drawn in from the vents located on the sides of the router.

Site Power Guidelines

The chassis has specific power and electrical wiring requirements. Adhering to these requirements ensures reliable operation of the system. Follow these precautions and recommendations when planning your site power for the chassis:

- The redundant power option provides a second, identical power supply to ensure uninterrupted power supply.
- Connect each power supply to a separate input power source. Otherwise, it results in total power failure to the system due to a fault in the external wiring or a tripped circuit breaker.
- To prevent loss of input power, ensure that the maximum load on each circuit is within the current ratings of the wiring and the breakers.
- Check the power at your site before installation, and periodically after installation, to ensure that you're receiving clean power. If necessary, install a power conditioner.
- Provide proper grounding to avoid personal injury and damage to the equipment due to power surges or lightning striking power lines. The chassis ground must be attached to a central office or other interior grounds system.



Note

The chassis installation must comply with all the applicable codes, and is approved for use with conductors. The ground bond-fastening hardware must be compatible and preclude loosening, deterioration, and electrochemical corrosion of hardware and joined material. Attachment of the chassis ground to a central office or other interior grounds system must be made with a 6-AWG gauge wire copper ground conductor.



Caution

This product requires an external surge protection device for both AC and DC power feeds to the For a DC power feed, the surge protective device (SPD) must handle common mode and differential mode surge as per the local standards.



Caution

The ACPSU requires external surge protection devices (SPD) for installations, where an electrical surge is higher than 2KV common mode and higher than 2KV differential mode. Failure to do so may result in permanent damage to the router. Following are the applicable router variants:

- N540-24Z8Q2C-SYS
- N540X-ACC-SYS
- N540-ACC-SYS
- N540X-16Z4G8Q2C-A
- N540X-12Z16G-SYS-A
- N540-28Z4C-SYS-A
- N540X-16Z8Q2C-A
- N540-12Z20G-SYS-A



Caution

The DCPSU requires external surge protection devices (SPD) for installations, where an electrical surge is higher than 2KV common mode and higher than 1KV differential mode. Failure to do so may result in permanent damage to the product. Following are the applicable router variants:

- N540-24Z8Q2C-SYS
- N540X-ACC-SYS
- N540-ACC-SYS
- N540X-16Z4G8Q2C-D
- N540X-12Z16G-SYS-D
- N540X-16Z8Q2C-D

Following are the applicable router variants that require external surge protection devices (SPD), where an

electrical surge is higher than 1KV common mode and higher than 1KV differential mode:

- N540-12Z20G-SYS-D
- N540-28Z4C-SYS-D

ElectricalCircuitRequirements

Each chassis requires a dedicated electrical circuit. If you equip the device with dual-power feeds, provide a separate circuit for each power supply to avoid compromising the power redundancy feature. The chassis supports both DC source or an AC source. Ensure that equipment grounding is present and observe power-strip ratings. Make sure that the total amperage rating of all the products plugged into the power strip does not exceed 80% of the rating.

Site Cabling Guidelines

These are the guidelines for wiring and cabling at your site:

- When preparing your site for network connections to the router, consider:
 - the type of cable required for each component, and the cable limitations.

Possible cable types are fiber, thick or thin coaxial, foil twisted-pair, or unshielded twisted-pair cabling.
 - the distance limitations for signaling, ElectroMagnetic Interference (EMI), and connector compatibility.
 - any additional interface equipment you need, such as transceivers, hubs, switches, modems, Channel Service Units (CSU), or Data Service Units (DSU).
- Before you install the router, keep all the additional external equipments and cables handy. For information about ordering these equipments and cables, contact a Cisco customer service representative.
- The extent of your network and the distances between the network interface connections depend, in part, on the following factors:
 - Signal type
 - Signal speed
 - Transmission medium
- The distance and rate limits referenced in the following sections are the IEEE-recommended maximum speeds and distances for signaling purposes. Use this information as a guideline when planning your network connections *prior to* installing the router.
- If wires exceed the recommended distances, or if wires pass between buildings, give special consideration to the effect of a lightning strike in your vicinity. The electromagnetic pulse caused by lightning or other high-energy phenomenon can easily couple enough energy into unshielded conductors to destroy electronic devices. If you have had problems of this sort in the past, you may want to consult experts in electrical surge suppression and shielding.

Asynchronous Terminal Connections

The router provides a console port to connect a terminal or computer for local console access. The router supports RS-232 asynchronous data with distance recommendations specified in the IEEE RS-232 standard.

Interference Considerations

When wires are run for any significant distance, there is a risk that stray signals will be induced onto the wires as interference. If interference signals are strong, they may cause data errors or damage equipment.

The following sections describe the sources of interference and how to minimize their effects on the router system.

Cisco NC5540 Router Hardware Installation Guide

Tools and Equipment


You need the following tools and equipment to install and upgrade the device and its components:

- ESD-preventive cord and wrist strap
- Antistatic mat or antistatic foam
- Number 1 and Number 2 Phillips-head screwdrivers
- #12-24 pan-head screws to secure the device to the equipment rack
- Cables for connecting to network ports (based on the configuration)
- Ethernet hub, switch, or PC with a network interface card for connecting to the Ethernet ports
- Console terminal that is configured for 115200 baud, 8 data bits, no parity, no flow control, and 2 stop bits
- Console cable for connecting to the console port
- Ratcheting torque screwdriver with a Phillips head that exerts up to 30-pound force per square inch (0.02-kilograms force per square millimeter (kgf/mm²)) of pressure
- Crimping tool as specified by the ground lug manufacturer
- Wire-stripping tools for stripping both 6 and 14-AWG wires
- Tap measure and level
- Ratcheting torque screwdriver with a Phillips head that exerts up to 15 inch-pounds (1.69 newton meters) of torque for attaching the ground wire to the device

Prepare Your Location

This section illustrates how the building that houses the chassis must be properly grounded to the earth ground.

Figure14:BuildingwithRackRoomConnectedtoEarthGround



PrepareYourself

This section illustrates how to prepare yourself before removing the chassis from the sealed antistatic bag.


The figures show how to wear the ESD strap around the wrist and how to connect the other end of the strap

to the ground. ESD wrist straps are the primary means of controlling static charge on personnel

.

Note: These images are for only representation purposes. The chassis' actual appearance and size would vary.

Figure 15: Wearing the ESD Strap



Prepare Rack for Router Installation

Install the chassis into a two-post standard rack with standard horizontal mounting rails. Before you mount the chassis into the rack, we recommend that you do the following:

Procedure

- Step 1** Place the rack where you plan to install the chassis. Ensure that the rack is grounded to earth.
- Step 2** Secure the rack to the floor.
- To bolt the rack to the floor, a floor bolt kit (also called an anchor embedment kit) is required. For information on bolting the rack to the floor, consult a company that specializes in floor mounting kits (such as Hilti; see [Hilti.com](https://www.hilti.com) for details).
- Makesure that floor mounting bolts are accessible, especially if an annual retorquing of bolts is required.

Cabinet Selection Guidelines

Equipment that is intended for installation in controlled environmental space has a average yearly level of contamination. Ventilated cabinets or racks can be used if pollutant levels are maintained within allowable limits.

Equipment intended for installation in outside plant (OSP) areas must have sealed cabinets with a heat exchanger that meet the IP66 or IP65 protection and low average yearly level of concentration of contaminants inside the cabinet.



Note Ventilated cabinets and racks are not recommended for OSP applications.

Table 10: Cabinet Type for Indoor and Outdoor Installation

Cabinet Type	Suitable for Indoor Installation?	Suitable for Outdoor Installation?
Open rack with no front and rear doors	Yes	No
Ventilated cabinets with normal air filter at intake and fans	Yes	No
Sealed cabinets with heat exchanger that meet NEMA-4 or protection	Yes	Yes
Sealed cabinets with air-conditioner that meet NEMA-4 or IP65 protection	Yes	Yes

Allowable limits for Environmental Pollutants

Concentration of pollutant levels in outdoor and indoor environment must be less than pollutant levels mentioned in Table 2.3 and Table 2.4 of NEBS GR-63-CORE Issue 5 Dec 2017, respectively. High concentration of pollutants have a negative impact on the equipment lifetime.

Allowable Temperature and Humidity

Maximum allowable temperature and humidity levels must be within the values that are mentioned in the data sheets. Do not install in places where condensation may occur, or where equipment is exposed to high humidity for long time, such as near the sea, rivers, and large water bodies.

Installations in Highly-corrosive Environment

Installation in highly corrosive area is not recommended. Examples of highly corrosive areas are a seashore, less than 10 meters from high traffic roadway, and areas having high industrial pollutants.

Periodic Measurement of Environmental Pollutants

We recommend that you check concentration of pollutants periodically. Necessary protection should be provided to ensure the equipment is not exposed to high concentration level of pollutants.

Unpack the Cisco NCS540 Router

Before you begin

Ensure that there is sufficient room around the chassis pallet for unpacking.

Procedure

Step1 Remove the accessory tray and the packing material.

Step2 Carefully set the packing material aside.


Tip

Be sure to save the packaging in case you need to return any of the components products.

Note

These images are for only representation purposes. The chassis' actual appearance and size would vary.

Figure 16: Unpacking the Device



366940

1	Regular Slotted Container (shipping box)	2	Foam end caps
3	Front corrugated cap	4	Front end of the product
5	Back end of the product	6	Accessory tray

Whattodonext

Table11:AccessoriesKit

Category	N540-28Z4C-SYS A/D	N540-12Z20G-SYS A/D	N540X-16Z4G8Q2C	N540X-16Z8Q2C-D	N540X-12Z16G-SYS A/D
19-inch rack mount brackets	N540-RCKMT-19-CLA / N540-RCKMT-19-CLD	N540-RCKMT-19-CLA / N540-RCKMT-19-CLD	N540-RCKMT-19-EGA / N540-RCKMT-19-EGD	N540-RCKMT-19-EGA / N540-RCKMT-19-EGD	N540-RCKMT-19-ACA / N540-RCKMT-19-ACD
23-inch rack mount brackets	N540-RCKMT-23-CLA / N540-RCKMT-23-CLD	N540-RCKMT-23-CLA / N540-RCKMT-23-CLD	N540-RCKMT-23-EGA / N540-RCKMT-23-EGD	N540-RCKMT-23-EGA / N540-RCKMT-23-EGD	N540-RCKMT-23-ACA / N540-RCKMT-23-ACD
ETSI rack mount brackets	N540-RCKMT-ETSI-CLA / N540-RCKMT-ETSI-CLD	N540-RCKMT-ETSI-CLA / N540-RCKMT-ETSI-CLD	N540-RKMT-ETSI-EGA / N540-RKMT-ETSI-EGD	N540-RKMT-ETSI-EGA / N540-RKMT-ETSI-EGD	N540-RCKMT-ETSI-ACA / N540-RCKMT-ETSI-ACD
Wall mount brackets	N540-WALLMT-CLA	N540-WALLMT-CLA	Not supported	Not supported	Not supported
Cable management brackets	N540-CBL-BRKT-CL	N540-CBL-BRKT-DN	N540-CBL-BRKT-EG	N540-CBL-BRKT-EG	N540-CBL-BRKT-AC



Note Most Cisco documentation is available online. The chassis Pointer Card that is shipped with your 500 Series Services Router contains links and information to other online documentation.



Note If the product is not in use, store the device in the initial packaged condition or in an ESD PE seal or silicagel.

The following accessories kit is applicable to the Cisco N540-24Z8Q2C-SYS, N540X-ACC-SYS, and N540-ACC-SYS variants.

Table12:AccessoriesKit

Category	Model
Cable management brackets	N540-CBL-GD-19 N540-CBL-GD
19-inch rack mount brackets	N540-RCKMT-19
23-inch rack mount brackets	N540-RCKMT-23

Category	Model
ETSI rackmount brackets	N540-RCKMT-ETSI



CHAPTER 4

Install the Device

Before you begin this task, ensure that you have read and understood the safety warnings in the *Standard Warning Statements* section of the *Safety Warnings* handout topic.

Installing the Cisco NCS540 involves these tasks:



Note All the installation instructions for Cisco N540-24Z8Q2C-SYS, N540X-ACC-SYS, N540-N540-28Z4C-SYS-A/D, N540-12Z20G-SYS-A/D, N540X-12Z16G-SYS-A/D and N540X-16Z4G8Q2C-A/D variants remain similar and any differences between the routers are specifically called out. The illustrations are for reference purpose only and may vary based on your Cisco NCS540 variant.

- [Rack Compatibility, on page 37](#)
- [Setup Device on Rack or Wall, on page 40](#)
- [Installing the Air Filter, on page 54](#)
- [Ground the Device, on page 69](#)
- [Install the AC Power Cables, on page 69](#)
- [Install the DC Power Cables, on page 71](#)
- [Port Connection Guidelines, on page 74](#)
- [Connect to the Console Port, on page 74](#)
- [Connect to the Management Ethernet Port, on page 76](#)
- [Connecting Timing Cables, on page 77](#)
- [Connecting a Cable to the GNSS Antenna Interface, on page 79](#)
- [Install and Remove Transceiver Modules, on page 80](#)
- [Connect Interface Ports, on page 89](#)
- [Maintain Transceivers and Optical Cables, on page 90](#)

Rack Compatibility

We recommend that you follow these rack specifications.

RackTypes

Figure17:RackspecificationEIA(19inchesand23inches)







Table13:RackspecificationEIA(19inchesand23inches)




PostType	RackType	RackFrontOpening (X)	RackMountingHole Centre-	MountingFlange Dimension(Z)
4Post	19inches(48.3 centimeters)	17.75inches(45 centimeters)	18.31inches(46.5 centimeters)	19inches(48.2 centimeters)
2Post				
4Post	23inches(58.4 centimeters)	21.75inches(55.24 centimeters)	22.31inches(56.6 centimeters)	23inches(58.4 centimeters)
2Post				

Figure18:FourPostRackType

4 – Post Type (Hole EIA Universal)		Width Available (X)	Compatibility
All 23" Type rack		552.45mm (21.75")	Yes
All ETSI rack (21" rack)		500.0mm (19.68")	Yes
19" Type rack		17.75" (450.8 mm)	Yes
L-Type Post		17.50" (444.5 mm)	No
19" Type Racks		17.75" (450.8 mm)	Yes
Flat-Post		17.50" (444.5 mm)	No
19" Type racks		17.75" (450.8 mm)	Yes
C- Type Post		17.50" (444.5 mm)	No

367456

Figure19:TwoPostRackType

2 – Post Type (Hole EIA Universal)	X – 19" Rack	Compatibility	X-23" Rack	Compatibility
 TYPE-I	17.75" (450.8 mm)	Yes	21.75" (552.45mm)	Yes
	17.50" (444.5 mm)	No	21.75" (552.45mm)	Yes
 TYPE-II	17.75" (450.8 mm)	Yes	21.75" (552.45mm)	Yes
	17.50" (444.5 mm)	No	21.75" (552.45mm)	Yes
 TYPE-III	17.75" (450.8 mm)	Yes	21.75" (552.45mm)	Yes
	17.50" (444.5 mm)	No	21.75" (552.45mm)	Yes
 L-TYPE	17.75" (450.8 mm)	Yes	21.75" (552.45mm)	Yes
	17.50" (444.5 mm)	No	21.75" (552.45mm)	Yes
 Uneven-TYPE	17.75" (450.8 mm)	Yes	21.75" (552.45mm)	Yes
	17.50" (444.5 mm)	No	21.75" (552.45mm)	Yes

367457

SetupDeviceonRackorWall

You can choose to either setup the Cisco NCS540 on a rack or wall mount it.



Note Wall mount is supported only on Cisco N540-24Z8Q2C-SYS, N540X-ACC-SYS, N540-ACC-N540-28Z4C-SYS-A/D, and N540-12Z20G-SYS-A/D routers.

Rack-Mount

The device is shipped with rack mounting brackets that are to be secured on the sides of the device.



Caution If the rack is on wheels, ensure that the brakes are engaged or the rack is otherwise stabilized.

Table14: CiscoNCS540RouterRack-MountKit

Quantity	PartDescription
2	Rack-mountbrackets
8	M4x0.7x6-mmPhillipsflat-headscrews
3 ³	M3x0.5x4-mmPhillipscountersinkscrews

³Topcoverorthenebskitisanoptionalaccessorytoimprovetheairflow,henceitmaynotbe apart ofyourstandardpackage.



Note Thedeviceisshippedwiththenewcablemanagementbrackets.Ifyourequiretheoldlongcable brackets,youneedtoorderA920-CBL-BRKT-H.


Table15: N540X-16Z4G8Q2CA/DRouterRack-MountKit

Quantity	PartDescription
2	Rack-mountbrackets
8	M3x0.5x6-mmPhillipsflat-headscrews

Procedure

- Step1** (Optional)AttachthetopcoverorthenebskitbyusingtheM3screwstothechassis.
- Step2** Attachtherack-mountbracketsandthecableguidestotherouterasfollows:
- The router has port-
 - Positionthebracketearsfacingfrontormiddlerack-mount,onthesideofthechassissothattheholesarealigned.
 - UsefourM4screwstoattachthebracketstothechassis.
 - RepeatSteps1band1cwiththeotherrack-mountbracketontheothersideoftherouter.

Figure20:InstallingRack-MountBrackets



1	TopcoverortheneBskit	2	Rack-mountbrackets
3	Powersupplyunit	-	-

Figure21:InstallingCableManagementand19inchRack-MountBracketsintheFront




Figure 22: Installing Cable Management and 19-inch Rack-Mount Brackets in the Middle




Figure 23: Installing 19-inch Rack-Mount Brackets in the Middle (N540X-16Z4G8Q2C-A/D)




Table16:Requirementforinstallingrack-mountbracketsinthemiddle

SerialNo	PartNumber	Quantity
1	700-118409-01	2
2	48-1363-01	8

Figure24:N540X-16Z4G8Q2C-A/Dchassiswith19inchrack-mountbracketsmountedatthemiddlewithcablemanagementbracketsinthe front




Table17:Requirementforinstallingrack-mountbracketsinthemiddlewithcablemanagementbracketsinthe front

SerialNo	PartNumber	Quantity
1	700-119475-02	2
2	48-1363-01	4
3	700-05613-01	2
4	48-0654-01	2

Figure25:N540X-16Z4G8Q2C-A/Dchassiswith19inchrack-mountanglemountedatthemiddleinstalledontwopost19inchrack




Table18:Requirementforinstallingrack-mountbracketsinthemiddleofatwopost19inchrack

SerialNo	PartNumber	Quantity
1	48-101690-01	4

Figure26:N540X-16Z4G8Q2C-A/Dchassiswith19inchrack-mountanglemountedatthefront




Table19:Requirementforinstallingrack-mountbracketsinthe front

SerialNo	PartNumber	Quantity
1	700-118409-01	2
2	48-1363-01	8

Figure27:N540X-16Z4G8Q2C-A/Dchassiswith19inchrack-mountanglemountedatthefrontinstalledontwopost19inchrack




Table20:Requirementforinstallingrack-mountanglemountedatthefrontinstalledontwopost19inchrackmountbrackets

SerialNo	PartNumber	Quantity
1	48-101690-01	4

Figure28:N540X-16Z4G8Q2C-A/Dchassiswith19inchrack-mountbracketsmountedatthefrontwithcablemanagementbracketatthefront




Table21:Requirementforinstallingrack-mountbracketsmountedatthefrontwithcablemanagementbracketatthefront

SerialNo	PartNumber	Quantity
1	700-05613-01	2
2	48-0654-01	2

Figure 29: Installing Cable Management and 23-inch Rack-Mount Brackets in the Front




Figure 30: Installing Cable Management and 23-inch Rack-Mount Brackets in the Middle





Figure31:InstallingCableManagementandETSIRack-MountBracketsintheMiddle



Step3 Installtherouterontothe2-postrackasfollows:

- a) Liftandpositiontherouterintopositionbetweenthe tworackposts.
- b) Movetherouteruntiltherack-mountbracketscomeincontactwiththetworackposts.
- c) Holdthechassisatlevelandhaveanotherwhilethesecondpersoninserttwoscrews(12-24or10-32,dependingon theracktype)ineachofthetworack-mountbrackets(usingatotaloffourscrews)andintotheagenutsorthreaded holesintheverticalrack-mountingrails.
- d) Tightenthe10-32screwsto20in-lb(2.26N.m)ortightenthe12-24screwsto30in-lb(3.39N.m).

WallMount

Installthewallmountingbracketsandcableguidesontothechassisbeforeyoumountthechassis onthewall.



Note The wall mount is supported only on Cisco N540-24Z8Q2C-SYS, N540X-ACC-SYS, N540-ACC-N540-28Z4C-SYS-A/D, and N540-12Z20G-SYS-A/D routers.

InstallWallBrackets

The device is shipped with wall mounting brackets that are to be secured on the sides of the device.

Procedure

Step1 Removethewallmountingbracketsfromtheaccessorykitandpositionthembesidethedevice.

Note
Youcaninstallthebracketsasshowninthefigure.

Figure32:InstallWallMountBrackets(N540-28Z4C-SYS-D)

Step2 Securethebrackettothedevicewiththerecommendedmaximumtorqueof10inch-


WallMounttheDevice



Note Whileyoumountthedevice,alwaysensurethatthepowersuppliesareatthetoppositi

Forthesupportofthedeviceandcables,ensurethatthedeviceisattachedsecurelytowallstuds or to a firmly attached plywood mounting backboard.

Figure33:WallMounttheDevice(N540-28Z4C-SYS-D)





Caution Before mounting the device, ensure that all unused holes at the sides of the device are always screwed.

Installing the Air Filter

This section describes installing the air filter, N540X-16Z4G8Q2C-F, on the following NCS540 router variants:

- N540X-16Z4G8Q2C-A
- N540X-16Z4G8Q2C-D



Note The maximum operating temperature is 60°C when air filters and dust covers are installed on the system. The maximum operating temperature increases to 70°C when air filters and dust covers are removed from the system.



Note The air filters are for one-month use and should be replaced every six months if needed.


Before you begin

- Complete the "[Rack-Mount, on page 40](#)" procedure.
- Since the air filter is installed from the top, make sure that there is approximately 2 rack units of space above the router.

Procedure

Step 1 Position the air filter on top of the air inlet side of the chassis as shown in the figure.


Figure34:Positiontheairfilter



Note
Locate the label "TOPREAR" on the air filter's stop bracket. The label serves as an installation guide indicating that this side of the air filter should be positioned at the top of the router chassis.


Step 2 From the top, slide the air filter to cover the air vents as shown in the figure.

Figure35:Slide the air filter



Note
There are three magnetic points on the air filter as shown in the figure. The magnetic points keep the air filter secured to the router chassis.

Figure36:Magneticpoints



Installtheairfilter(N540-FR-KIT-EG)(frontandsideviews)

This section describes installing the air filter, N540-FR-KIT-EG, on the following NCS540 router variants:

- N540X-16Z4G8Q2C-A
- N540X-16Z4G8Q2C-D



Note The air filters are for one-months and replace it every six months if needed.


Before you begin

- Complete the "[Rack-Mount, on page 40](#)" procedure.
- Since the air filter is installed from the top, make sure that there is approximately 2 rack units of space above the router.

Procedure

Step 1 Mount the cable management onto the mounting gear on both sides.

Figure37:Mountthecablemanagement




Part	PartNumber	Quantity
1-Cable management	800-52079-01	2

Note
Use thumbscrew to fix cable management with track mount bracket.

Step2 Assemble the front air filter cover.


Figure38:Frontairfilter



Part	PartNumbe	Quanti
1- Cablemanagement	800-52079- 01	2
2-Airfilterfront cover	700- 137145-01	1


Step3 Fixtheside-mountedairfilterontotheairbaffle(RH).

Figure39:Side-mountedairfilter



Part	PartNumbe	Quanti
1-Airfilter	800-112483-02	1
2-Air baffle	700-137173-01	1

Figure40:Airfilter



Part	PartNumbe	Quanti
1-Airbaffle- Rightsidewithairfilter	700-137173-01	1
	800-	


Part	PartNumbe	Quanti
2-Airbaffleleftside	700- 137549-01	1

Warning

Airfilterbafflewithairfiltershouldbeassembledinrightsideofthechassisairinlet.

Step4 Mountboththerightandleftairbafflesonthechassis.

Figure41:Mountingairfiltersonbothsidesofchassis



525080

Part	PartNumbe	Quanti
ExhaustBaffle-1	700-137540-01	1

Part	Part Number	Quantity
Right side air baffle with filter	700-137173-01	1
2	800-	

Warning

We recommend that you use only the screws with part number 48-101690-01 to mount the chassis on rack. Other screws are not recommended for the side filter assembly.

Warning

The ports without optics should be closed with dust caps.

Install the air filter (N540-FR-KT-EG-200) (front and side views)

This section describes installing the air filter, N540-FR-KT-EG-200, on the following NCS540 router variants:

- N540X-16Z4G8Q2C-A
- N540X-16Z4G8Q2C-D



Note The air filters are for one-month use and replace it every six months if needed.


Before you begin

- Complete the "[Rack-Mount, on page 40](#)" procedure.
- Since the air filter is installed from the top, make sure that there is approximately 2 rack units of space above the router.

Procedure

Step 1 Fix mounting gear on both sides of the chassis and fasten with screws.

Figure42:Fixmountingearsonchassis




525228

Par	PartNumbe	Quanti
1	700-138377-01	2
2	48-1363-1	8

Step2 MountN540X-16Z4G8Q2C-A/Dchassiswith19-inchrack-mountangleatthefrontontwopost19-inchrack.

Figure43:N540X-16Z4G8Q2C-A/Dchassiswith19-inchrack-mountanglemountedatthefrontinstalledontwopost19-inchrack




Requirementforinstallingrack-mountanglemountedatthefrontinstalledontwopost19-inchrackmountbrackets

Part	Part Number	Quantity
1	48-101690-01	4

Step3 Assembletheairfilterontheventareaofairfiltertray.


Figure44:Airfilterwithtray



Part	PartNumber	Quantity
1-Air tray	800-52147-01	1
2-Air filter	800-52113-01	1

Step4 Mounttheairfilterontherackmountguideandtightenwithcaptivescrewonhetray.

Figure 45: Mounting air filter on rack and both sides of chassis




525232

Part	PartNumbe	Quanti
1-Air tray	800-52147-01	1


Step5 Mounttheairfiltercoverontopofthetrayandfastenwithcaptivescrewafterfixingalltheo

Figure46:Airfiltercovermounteronairfiltertray



Part	Part Number	Quantity
1-Air filter cover	700-138383-01	1

Figure 47: Air filter installed on chassis



Warning
We recommend that you use only the screws with part number 48-101690-01 to mount the chassis on rack. Other screws are not recommended for the side filter assembly.

Warning
The ports without optics should be closed with dust caps.

GroundtheDevice

Before you begin this task, ensure that you have read and understood the safety warnings in the Preventing ESDDamage section of the *Safety Warnings* handout topic.


Before you connect the power or turn on the power to the device, you must provide an adequate device ground (earth) connection to your device.

This section describes how to ground the device. The grounding lug location is on the backpane of the device.

Procedure

Step1 Verify that the ground cable is connected to the top of the rack and according to local site practice.

Figure48:GroundLug



Step2

Attach one end of the shelf ground cable (#6AWG cable) to the ground point on the rear of the chassis using the specified

dual-hole lug connector.

- a) Use a wire-stripping tool to remove approximately 0.75 inches (19mm) of the covering from the end of the grounding cable.
- b) Insert the stripped end of the grounding cable into the open end of the grounding lug.
- c) Use the crimping tool to secure the grounding cable in the grounding lug.
- d) Remove the adhesive label from the grounding pad on the chassis.
- e) Place the grounding lug against the grounding pad so that there is solid metal-to-metal contact, and insert the two M4 screws with washers through the holes in the grounding lug and into the grounding pad.
- f) Ensure that the lug and cable do not interfere with other equipment.
- g) Prepare the other end of the grounding cable and connect it to an appropriate grounding point in your site to ensure adequate earth ground.


InstalltheACPowerCables

To install the AC power cables in the power supply slots:

Procedure

- Step 1 Plug the power supply cord in the power supply module.
- Step 2 Insert the power supply cord into the tie [1,3] and tighten the tie around the power supply cord as shown in figure below.

Figure 49: Attach the AC Power Tie-and-Clip Cord



Note

These images are for only representation purposes. Certain variants of Cisco NCS540 do not include a tie for the power supply cord.

Activate an AC Power Supply Module

Perform the following procedure to activate an AC power supply:

Procedure

- Step1 Plugthepowercordintothepowersupply.
- Step2 ConnecttheotherendofthepowercordtoanAC-inputpowersource.
- Step3 VerifypowersupplyoperationbycheckingiftherespectivepowersupplyfrontpanelLED(PM0orPM1)
- Step4)isgreen.
- Step5 IftheLEDsindicateapowerproblem,see*Troubleshooting*fortroubleshootinginformation.

Note

IfyouareconnectingaredundantACpowersupply,ensurethateachpowersupplyisconnectedtoaseparatepower sourceinordertopreventpowerlossintheeventofapowerfailure.

InstalltheDCPowerCables



- Note WheninstallingDCpowersupply,use12AWG,90°Ctemperatureratedcable.Thererecommen is3metersmaximumfromsource.Upto5metersuse10AWG,andupto3metersuse12A WG,90°C temperatureratedcableandforotherlengthcontactCisco.



- Note ForN540X-16Z4G8Q2C-A/DandN540X-16Z8Q2C- 90°Ctemperatureratedcable.Thererecommendedcablelengthis3metersmaximumfromso urce.Upto5 metersuse14AWG,andupto3metersuse16AWG,90°Ctemperatureratedcableandforothe rlengthcontact Cisco.




- Note
- Alwaysensurethatthebuilding'sinstallationforshort- 15A.
 - WerecommendedusingaCircuitbreakerorafastactingfusewithamaximumDCrating of10Afor overcurrentprotection.



- Note TheDCconnectororterminalblockhasaninbuiltscrewandcagenuttowhichtorqueof1.3to1. beapplied.

Figure50:DCConnectorwithInbuiltScrew




A	0.74in.(1.88 cm)	C	0.18in. (0.46cm)
B	0.25in.(0.64 cm)	D	0.14in. (0.36cm)
M	0.62in.(1.58 cm)		

ToattachtheDCpowersupplies:

Procedure

- Step1 Locatetheterminalblockplug.
- Step2 InserttheDC-inputpowersourcewiresintothe terminalblockplug.
- Step3 AttachtheDCsupplywiresusingthedesignatedscrews.
- Step4 Usearatchetingtorquescrew drivertotorquetheterminalblockplugcaptive screw.Seethefollo

Figure51:AttachtheDCPowerSupplyWires



Note
These images are for only representation purposes. Certain variants of Cisco NCS540 may vary.

Activate a DC Power Supply Module

Perform the following procedure to activate a DC power supply:

Procedure

- Step1** Remove the tape from the circuit-breaker router handle, and restore power by moving the circuit-breaker to the On (I) position.
- Step2**
- Verify the power supply operation by checking whether the respective power supply front panel LED (PM0 or PM1) is green.
- Step3** If the LEDs indicate any issues with power problem, see *Troubleshooting*.
- Step4** If you are also connecting a redundant DC power supply, repeat these steps for the second power source.

Note
If you are connecting a redundant DC power supply, ensure that each power supply is connected to a separate power source in order to prevent power loss in the event of a power failure.

PortConnectionGuidelines

Depending on the chassis, you can use Quad Small Form-Factor Pluggable Plus (QSFP+), QSFP28, SFP, SFP+, and RJ45 connectors to connect the ports on the line card to other network devices.

To prevent damage to the fiber-optic cables, we recommend that you keep the transceivers disconnected from their fiber-optic cables when installing the transceiver in the line card. Before removing a transceiver from the router, remove the cable from the transceiver.

To maximize the effectiveness and life of your transceivers and optical cables, do the following:

- Wear an ESD-preventative wrist strap that is connected to an earth ground whenever handling transceivers. The router is typically grounded during installation and provides an ESD port to which you can connect your wrist strap.
- Do not remove and insert a transceiver more often than is necessary. Repeated removals and insertions can shorten its useful life.
- Keep the transceivers and fiber-optic cables clean and dust free to maintain high signal accuracy and to prevent damage to the connectors. Attenuation (loss of light) is increased by contamination and should be kept below 0.35 dB.
 - Clean these parts before installation to prevent dust from scratching the fiber-optic cable ends.
 - Clean the connectors regularly; the required frequency for cleaning depends upon the environment. In addition, clean connectors when they are exposed to dust or accidentally touched. Both wet and dry cleaning techniques can be effective; refer to your site's fiber-optic connection cleaning procedures.
 - Do not touch the ends of connectors. Touching the ends can leave fingerprints and cause other contamination.
- Inspect routinely for dust and damage. If you suspect damage, clean and then inspect fiber ends under a microscope to determine if damage has occurred.

Connect to the Console Port

Before you create a network management connection for the router or connect the router to the network, you must create a local management connection through a console terminal and configure an IP address for the router. You also can use the console to perform the following functions (each of which can be performed through the management interface after you make that connection):

- Configure the router using the command-line interface (CLI).
- Monitor network statistics and errors.
- Configure Simple Network Management Protocol (SNMP) agent parameters.
- Download software updates.

The system console port is an RJ-45 receptacle for connecting a data terminal to perform the initial configuration of Cisco NCS540 fixed-port chassis. The console cable is shipped with the hardware.

Cisco NCS540 Router Hardware Installation Guide




Note OnlyRJ45toDB-9adaptercableisprovidedinthepackage.



Caution Werecommendyoutosettheterminaltotheseoperationalvalues:115200bps,8databits,no bitsandflowcontrolasnone.Settinganyflowcontrol,maycausecongestionintheconsolebu fferleading touunexpectedbehavior.

Figure52:ConnectingtheUSBConsoleCabletotheChassis



1	RJ45Port	2	USBType-Aconsolecable
---	----------	---	-----------------------

Followthisproceduretoconnectadataterminaltotheconsoleport.

368290

Before you begin

- The router must be fully installed in its rack, connected to a power source, and grounded.
- The necessary cabling for the console, management, and network connections must be available.
 - An RJ-45 rollover cable and DB9F/RJ-45 adapter are provided in the router accessory kit.
 - Network cabling should already be routed to the location of the installed router.

Procedure

- Step 1 Set your terminal to these operational values: 115200 bps, 8 data bits, no parity, and 2 stop bits and flow control. Setting any flow control may cause congestion in the console buffer leading to unexpected behavior.
- Step 2 Attach the terminal end of the cable to the interface port on the data terminal.
- Step 3 Attach the other end of the cable to the console port.

Following table represents the RJ-45 cable pin-out information.

Table 22: RJ-45 Straight-through Cable Pin-outs

RJ-45 Pin	Signal
1	—
2	—
3	Tx
4	Ground (GND)
5	GND
6	Rx
7	—
8	—

Connect to the Management Ethernet Port


The management Ethernet port provides out-of-band management, which enables you to use the command-line interface (CLI) to manage the router by its IP address. This port uses a 10/100/1000 Ethernet connection with an RJ-45 interface.



Note To prevent an IP address conflict, do not connect the management Ethernet port until the initial setup is complete.

To connect cable to the system management port, attach Category 5 cables directly to the RJ-45 receptacle on the management Ethernet port.

Figure 53: Console Port



Note To comply with GR-1089-CORE, the intra-cabling or wiring that is grounded at both ends.

Before you begin

You must complete initial router configuration.

Procedure

- Step1 Plug the cable directly into the RJ-45 receptacle.
- Step2 Connect the network end of your RJ-45 cable to a switch, hub, repeater, or other external equipment.

Connecting Timing Cables



Note When installing the cable to the RSPs, we recommend that you leave a service loop of extra fan tray removal.

The following sections describe how to connect timing cables to the router:

Connecting a Cable to the BITS Interface

The following steps describe how to connect a cable to the router's BITS port:

Procedure

- Step1 Confirm that the router is powered off.
- Step2 Connect one end of the cable to the BITS port using a straight-through, shielded RJ48C-to-
- Step3 RJ48C cable. Connect the other end to the BITS patch cord demarcation panel at your site.
- Step4 Turn on the power to the router.

Note

The use of two BITS sources or a Y-cable is optional. Each BITS input port is routed to both the RSPs, so that the SETS device on each RSP has visibility to both the BITS inputs.

Warning

To comply with the Telcordia GR-1089 NEBS standard for electromagnetic compatibility and safety, connect the BITS port only to intra-building or unexposed wiring or cable. The intra-building cable must be shielded and the shield must be grounded at both ends. The intra-building port(s) of the equipment or subassembly must not be metalically connected to interfaces that connect to the OSP or its wiring. These interfaces are designed for use only as intra-building interfaces (Type 2 or Type 4 ports as described in GR-1089-CORE) and require isolation from the exposed OSP cabling. The addition of Primary Protectors is not sufficient protection in order to connect these interfaces metalically to OSP wiring.

Connecting Cable to a GPS Interface

The following sections describe how to connect cables from the router to a GPS unit for input or output timing or frequency:

Connecting a Cable to the Input 10 MHz or 1 PPS Interface

Procedure

- Step1 Connect one end of a mini-coax cable to the GPS unit.
- Step2 Connect the other end of the mini-coax cable to the 10 MHz or 1 PPS port on the RSP of the router.

ConnectingaCabletotheOutput10MHzor1PPSInterface

Procedure

- Step1 Connectoneendofamini-coaxcabletotheSlaveunit.
- Step2 Connecttheotherendofthemini-coaxcabletothe10MHzor1PPSportoftherouter.

ConnectingaCabletotheToDInterface

Procedure

- Step1 Connectoneendofastraight-throughEthernetcabletotheGPSunit.
 - Step2 Connecttheotherendofthestraight-throughEthernetcabletotheToDor1-PPSportoftherouter.
- Warning**
To comply with the Telcordia GR-1089 NEBS standard for electromagnetic compatibility and safety, connect the ToD port only to intra-building or unexposed wiring or cable. The intra-building cable must be shielded and the shield must be grounded at both ends. The intra-building port(s) of the equipment or subassembly must not be metalically connected to interfaces that connect to the OSP or its wiring. These interfaces are designed for use as intra-building interfaces only (Type 2 or Type 4 ports as described in GR-1089-CORE) and require isolation from the exposed OSP cabling. The addition of Primary Protectors is not sufficient protection in order to connect these interfaces metalically to OSP wiring.

Note
For more information about GPS-port pinouts, see *Pinout* table.

ConnectingaCabletotheGNSSAntennaInterface



Note The GNSS module is not hot swappable.

1. Connect one end of a shielded coaxial cable to the GNSS RF IN port.
2. SMA Mating cable assembly Torque should be maintained within 3 in-lb. For Cisco N540-ACC-SYS, and Cisco N540-ACC-SYS nut and washer may be removed when you use a slightly longer mating SMA connector to ensure contact with the connector.
- 3.

Connect the other end of the shielded coaxial cable to the GNSS antenna. Use a passive splitter if more than one GNSS module are fed from a single antenna.

Install and Remove Transceiver Modules

Install and Remove SFP Modules

Before you remove or install an SFP or SFP+ module, read the installation information in this section.



Warning **Statement 1051**—Laser Radiation


Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments.



Caution

Protect the line card by inserting a clean SFP/optical module cage when there is no SFP or SFP+ module installed.

Figure 54: SFP/SFP+ Module Cage Cover



Caution

Protect the SFP or SFP+ modules by inserting clean dust covers into them after the cables are removed. Be sure to clean the optics surfaces of the fiber cables before you plug them back into the optical ports of another module. Avoid getting dust and other contaminants into the optical ports of your SFP or SFP+ modules, because the optics do not work correctly when obstructed by dust.



Caution

We strongly recommend that you do not install or remove the SFP or SFP+ module with fiber attached to it because of the potential of damaging the cable, the cable connector, or the optical interface in the module. Disconnect all cables before removing or installing an SFP or SFP+ module. Removing and inserting a module can shorten its useful life, so you should not remove and insert modules any more than is absolutely necessary.




Note When installing an SFP or SFP+ module, you should hear a click as the triangular pin on the bottom of the module snaps into the hole in the receptacle. The click indicates that the module is correctly seated and secured in the receptacle. Verify that the modules are completely seated and secured in their assigned receptacles on the line card by firmly pushing on each SFP or SFP+ module.

BaleClasp SFP or SFP+ Module

The baleclasp SFP or SFP+ module has a clasp that you use to remove or install the module (see the figure below).

Figure 55: BaleClasp SFP or SFP+ Module




Install a BaleClasp SFP or SFP+ Module

To install this type of SFP or SFP+ module, follow these steps:

Procedure

- Step 1 Attach an ESD-
- Step 2 preventiv wrist or ankle strap and follow its instructions for use.
- Step 3 Close the baleclasp before inserting the SFP module.

Figure 56: Installing a BaleClasp SFP Module into a Port



Note When installing an SFP or SFP+ module, you should hear a click as the triangular pin on the bottom of the SFP module snaps into the hole in the receptacle. This click indicates that the module is correctly seated and secured in the receptacle.

Verify that the SFP modules are completely seated and secured in their assigned receptacles on the line card by firmly pushing on each SFP module.

Remove a Bale Clasp SFP or SFP+ Module

To remove this type of SFP or SFP+ module, follow these steps:

Procedure

Step 1 Attach an ESD-preventive wrist or ankle strap and follow its instructions for use.

Step 2 Disconnect and remove all interface cables from the ports; note the current connections of the cables to the line card.

Step 3

Open the bale clasp on the SFP module with your index finger, as shown in the figure below. If the bale clasp is obstructed and you cannot use your index finger to open it, use a small flat-blade screwdriver or other long, narrow instrument to open the bale clasp.


Step 4

Grasp the SFP module between your thumb and index finger and carefully remove it from the port, as shown in the figure below.

Note

This action must be performed during your first instance. After all the ports are repopulated, this may not be possible.

Figure57:RemovingaBaleClaspSFPorSFP+Module



Step5

PlacetheremovedSFPmoduleonanantistaticmat,orimmediatelyplaceit inastaticshieldingbagifyouplantoreturn ittothefactory.

Step6

ProtectyourlinecardbyinsertingacleanSFPmodulecagecoversintotheopticalmodulecagewhenthereisnoSFP moduleinstalled.

InstallandRemoveQSFPTransceiverModules




Note Inthissection,QSFPpreferstoQSFP+,QSFP28,andQSFP-
[HandlingGuide](#)foradditionaldetailsonopticaltransceivers.

Thissectionprovidestheinstallation,cabling,andremovalinstructionsfortheQuadSmallForm-FactorPluggable(QSFP)transceivermodules.Themodulesarehot-swappableinput/output(I/O)devices that connect the system's module port electrical circuitry with either a copper or a fiber-optic network.

Thefollowingfigureshowsthe400-GigabitQSFP-DDtransceivermodule.

Figure58:400-GigabitQSFP-DDTransceiverModule



1	Pull-tab	2	QSFP-DDtransceiverbody
3	Electricalconnectiontothemodulecircuitry		



Warning **Statement1079—HotSurface**
Thisiconisahotsurfacewarning.Toavoidpersonalinjury,donottouchwithoutproperprotection.




Overview

The40-Gigabit(GE)QSFP+and100Gigabit(QSFP28)transceivermoduleisahot-swappable,parallel fiber-opticalmodulewith4independentopticaltransmitandreceivechannels.Thesechannelscant erminate inanother40-GigabitQSFP+transceiver,orthechannelscanbeprokenoutto4separate10-GigabitSFP+

transceivers. The QSFP+ transceiver module connects the electrical circuitry of the system with an optical external network.

The following figures show the 40-Gigabit optical QSFP+ transceiver. The transceiver is used primarily in short-reach applications in switches, routers, and data center equipment where it provides high density than SFP+ modules. The 100-Gigabit optical QSFP28 transceiver is similar to the 40-Gigabit optical QSFP transceiver.

Figure 59: 40-Gigabit QSFP+ Transceiver Module (Optical)



RequiredToolsandEquipment

You need these tools to install the transceiver modules:

- Wrist strap or other personal grounding device to prevent ESD occurrences.
- Antistatic mat or antistatic foam to set the transceiver on.
- Fiber-optic end-face cleaning tools and inspection equipment.

For information on inspecting and cleaning fiber-optic connections, see [Maintaining Transceivers and Optical Cables](#).

Installthe100-GigabitTransceiverModule

The QSFP+ or QSFP28 transceiver module can have either a bail-clasplatch or a pull-tab latch. Installation procedures for both types of latches are provided.

Caution

The QSFP+ or QSFP28 transceiver module is a static-sensitive device. Use an individual grounding device when handling QSFP+ or QSFP28 transceiver modules or coming into contact with system modules.

To install a QSFP+ or QSFP28 transceiver module, follow these steps:

Procedure

Step1 Attach an ESD wrist strap to yourself and a properly grounded point on the chassis or the rack.

Step2 Remove the QSFP+ or QSFP28 transceiver module from its protective packaging.

Step3

Check the label on the QSFP+ or QSFP28 transceiver module body to verify that you have the correct model for your network.

Step4 For optical QSFP+ or QSFP28 transceiver modules, remove the optical bore dust plug and set it aside.


Step5 For QSFP+ or QSFP28 transceiver modules equipped with a pull-tab, hold the transceiver so that the identifier label is on the top.

Step6 For QSFP+ or QSFP28 transceiver modules equipped with a bail-clasp latch, keep the bail-clasp aligned in a vertical position.

Step7

Align the QSFP+ or QSFP28 transceiver module in front of the module's transceiver socket opening and carefully slide the QSFP+ or QSFP28 transceiver into the socket until the transceiver makes contact with the socket electrical connector (see the figure below).

Figure 60: Installing the 100-Gigabit QSFP28 Transceiver Module (Optical Transceiver Equipped with a Bail-Clasp Latch Shown)




Step8

Press firmly on the front of the QSFP+ or QSFP28 transceiver module with your thumb to fully seat the transceiver in the module's transceiver socket (see the below figure).

Caution

If the latch is not fully engaged, you might accidentally disconnect the QSFP+ or QSFP28 transceiver module.

Figure61:Seatingthe100-GigabitQSFP28TransceiverModule(OpticalTransceiverEquippedwithaBail-ClaspLatchShown)



Step9

For optical QSFP+ or QSFP28 transceiver modules, reinstall the dust plug into the QSFP+ or QSFP28 transceiver optical bore until you are ready to attach the network interface cable. Do not remove the dust plug until you are ready to attach the network interface cable.

Attach the Optical Network Cable

Before you begin

Before you remove the dust plugs and make any optical connections, follow these guidelines:

- Keep the protective dust plugs installed in the unplugged fiber-optic cable connectors and in the transceiver optical bores until you are ready to make a connection.
- Inspect and clean the MPO connector end faces just before you make any connections. For complete information on inspecting and cleaning fiber-optic connections, see the [Inspection and Cleaning Procedures for Fiber-Optic Connections](#) document.
- Grasp the MPO connector only by the housing to plug or unplug a fiber-optic cable.



Note QSFP transceiver modules are keyed to prevent incorrect insertion.




Note

The multiple-fiber push-cables with either physical contact (PC) or ultra-physical contact (UPC) flat polished face types. The MPO connectors on the optical QSFP transceivers do not support network interface cables with an angle-polished contact (APC) face type.

Procedure

- Step 1 Remove the dust plugs from the optical network interface cable MPO connectors. Save the dust plugs for future use. Inspect and clean the MPO connector's fiber-optic end faces.
- Step 2 Remove the dust plugs from the transceiver module optical bores.
- Step 3 Immediately attach the network interface cable MPO connector to the transceiver module (see the
- Step 4

Figure 62: Cabling a Transceiver Module



Remove the 100-Gigabit QSFP28 Transceiver Module



Caution

The QSFP+ or QSFP28 transceiver module is a static-sensitive individual grounding device when handling QSFP+ or QSFP28 transceiver modules or when coming into contact with modules.


To remove a QSFP+ or QSFP28 transceiver module, follow these steps:

Procedure

- Step 1 For optical QSFP+ or QSFP28 transceiver modules, disconnect the network interface cable from the QSFP transceiver connector.

- Step2 For QSFP+ or QSFP28 transceiver modules equipped with a bail-clasp latch (see the below figure, top view):
- Pivot the bail-clasp down to the horizontal position.
 - Immediately install the dust plug into the transceiver's optical bore.
 - Grasp the sides of the QSFP+ or QSFP28 transceiver and slide it out of the module socket.
- Step3 For QSFP+ or QSFP28 transceiver modules equipped with a pull tab latch (see the below figure, bottom view):
- Immediately install the dust plug into the transceiver's optical bore.
 - Grasp the tab and gently pull to release the transceiver from the socket.
 - Slide the transceiver out of the socket.

Figure 63: Removing the 100-Gigabit QSFP28 Transceiver Module



- Step4 Place the QSFP+ or QSFP28 transceiver module into an antistatic bag.

Connect Interface Ports

You can connect optical interface ports on with other devices for network connectivity.

Connect a Fiber-Optic Port to the Network

Depending on the model that you are using, you can use either QSFP+ or QSFP28 transceivers. Some transceivers work with fiber-optic cables that you attach to the transceivers and other transceivers work with pre-attached copper cables. When installing fiber-optic cables for a port, you must install SFP transceivers for 1-Gigabit optical ports or install SFP+ transceivers for 10-Gigabit optical ports or QSFP+ transceivers for 100-Gigabit ports before installing the fiber-optic cable in the transceivers.



Caution Removing and installing a transceiver can shorten its useful life. Do not remove and insert transceivers more than absolutely necessary. We recommend that you disconnect cables before installing or removing transceivers to prevent damage to the cable or transceiver.

Disconnect Optical Ports from the Network

When you need to remove fiber-optic transceivers, you must first remove the fiber-optic cables from the transceiver before you remove the transceiver from the port.

Maintain Transceivers and Optical Cables

To maintain high signal accuracy and to prevent damage to the connectors, transceivers and fiber-optic cables must be kept clean and free of dust. Attenuation (loss of light) is increased by contamination and should be below 0.35 dB.

Consider the following maintenance guidelines:

- Transceivers are static sensitive. To prevent ESD damage, wear an ESD-preventative wrist strap that is connected to the grounded chassis.
- Do not remove and insert a transceiver more than it is necessary. Repeated removals and insertions can shorten its useful life.
- Keep all optical connections covered when not in use. Clean them before use to prevent dust from scratching the fiber-optic cable ends.
- Do not touch the ends of connectors. Touching the ends would leave fingerprints and cause other contamination.
- Clean the connectors regularly; the required frequency of cleaning depends upon the environment. In addition, clean connectors if they are exposed to dust or have been accidentally touched. Both wet and dry cleaning techniques can be effective; refer to your site's fiber-optic connection cleaning procedures.
- Inspect routinely for dust and damage. Clean and then inspect fiber ends under a microscope to determine whether any damage has occurred.



CHAPTER 5

Configure the Device

Before you begin this task, ensure that you have read and understood the safety warnings in the [Safety with Electricity](#) section of the [Safety Warnings](#) handout topic.

Configuring the Cisco NCS540 involves these tasks:

- [Create the Initial Router Configuration, on page 91](#)
- [Verify Device Installation, on page 93](#)

Create the Initial Router Configuration

You must assign an IP address to the router management interfaces so that you can then connect the router to the network.

When you initially power up the router, it boots up and asks a series of questions to help configure the router.

To enable you to connect the router to the network, you can use the default choices for each configuration except for the IP address, which you must provide.



Note Be aware of the router's unique name to identify it among the other devices in the network.

Before you begin

- A console device must be connected with the router.
- The router must be connected to a power source.
- Determine the IP address and netmask needed for the Management interfaces: MgmtEth0/RP0/CPU0/0 and MgmtEth0/RP1/CPU0/0:

Procedure

Step 1 Power up the router.

The LEDs on each power supply light up (green) when the power supply units are sending power to the router, and the software asks you to specify a password to use with the router.

Step 2

When the system is booted up for the first time, a new username and a password is to be created. The following prompt appears:

```
!!!!!!!!!!!!!!!!!!!!!!NO root-system username is configured. Need to configure root-system username. !!!!!!!!!!!!!!!!!!!!!!!
```

```
---Administrative User Dialog---
```

```
Enter root-system username:
%Entry must not be null.
```

```
Enter root-system username: root
Enter secret:
Use the 'configure' command to modify this configuration.
User Access Verification
```

```
Username: root
Password:
```

```
RP/0/RP0/CPU0:ios#
```

Step 3 Enter a new password to use for this router.

The software checks the security strength of it and rejects your password if it is not considered to be a strong password.

To increase the security strength of your password, make sure that it adheres to the following guidelines:

- At least eight characters
- Minimizes or avoids the use of consecutive characters (such as "abcd")
- Minimizes or avoids repeating characters (such as "aaa")
- Does not contain recognizable words from the dictionary
- Does not contain proper names
- Contains both uppercase and lowercase characters
- Contains both numbers and letters

Note

Clear text passwords cannot include the dollar sign (\$) special character.

Tip

If a password is trivial (such as a short, easy-to-decipher password), the software rejects the password configuration. Be sure to configure a strong password as described by the guidelines in this step. Passwords are case sensitive. If you enter a strong password, the software asks you to confirm the password.

Step 4 Reenter the password.

When you enter the same password, the software accepts the password.

Step 5 Enter the IP address for the management interface.

Step 6 Enter a network mask for the management interface.

Step 7

The software asks whether you want to edit the configuration. Enter **n** to not edit the configuration.

Step 8 The software asks whether you want to save the configuration. Enter **y** to save the configuration.

Verify Device Installation

After installing the Cisco NCS540 Router, you can use the **show** commands to verify the installation and configuration. If any issue is detected, take corrective action before making further configurations.

Procedure

Step 1 **show inventory**

Example:

```
#show inventory
```

Displays information about the field replaceable units (FRUs), including product IDs, serial numbers, and version IDs.

Step 2 **admin show environment**

Example:

```
#admin show environment
```

Displays all environment-related router information.

Step 3 **show environment temperature**

Example:

```
#show environment temperature
```

Displays temperature readings for card temperature sensors. Each system controller, route processor, line card, and fabric card has temperature sensors with two thresholds:

- **Minor temperature threshold:** when a minor threshold is exceeded, a minor alarm occurs and the following actions occur for all four sensors:

- System messages displayed
- SNMP notifications (if configured) sent
- Log environmental alarm event triggered (can be reviewed by running the show alarm command).

- **Major temperature threshold:** when a major threshold is exceeded, a major alarm occurs and the following actions occur:

- For sensors 1, 3, and 4 (outlet and on-board sensors), the following actions occur:
 - System messages displayed
 - SNMP notifications (if configured) sent
 - Log environmental alarm event triggered (can be reviewed by running the show alarm command).

- For sensor 2 (intake sensor), the following actions occur:

- If the threshold is exceeded in a switching card, only that card is shutdown.

- If the threshold is exceeded in an active route processor card with HA-standby or standby present, only that route processor card is shutdown and the standby route processor card takes over.
- If you do not have a standby route processor card in your router, you have up to 2 minutes to decrease the temperature. During this interval, the software monitors the temperature every 5 seconds and continuously sends system messages as configured.

Note

We recommend that you install dual route processor cards. If you are using a router without dual route processor cards, we recommend that you immediately replace the fan card even if just one fan is not working.

Step4 **hw-module location <loc> shutdown or [no] hw-modules shutdown location <loc>**

Example:

```
#hw-module location <loc> shutdown
```

Power supply shuts down a card gracefully.

Step5 **show environment power**

Example:

```
#show environment power
```

Displays the power usage information for the entire router.

Step6 **show environment voltage**

Example:

```
#show environment voltage
```

Displays the voltage for the entire router.

Step7 **show environment current**

Example:

```
#show environment current
```

Displays the current environment status.

Step8 **show environment fan**

Example:

```
#show environment fan
```

Displays the status of the fan trays.



CHAPTER 6

Replace Fan Module and Power Supply

Before you begin this task, ensure that you have read and understood the safety warnings in the [Safety with Electricity](#) section of the [Safety Warnings](#) handout topic.



Note

Replacing the fan module is applicable only for Cisco N540X-16Z4G8Q2C-A/D, N540-N540X-ACC-SYS, and N540-ACC-SYS variants.



Note

Replacing power supply module is applicable only for Cisco N540-24Z8Q2C-SYS, N540X-N540X-ACC-SYS, and N540-ACC-SYS variants.

- [Replace Fan Module, on page 95](#)
- [Replace Power Supply, on page 96](#)

Replace Fan Module



Caution

If you cannot replace a fan tray within three minutes, we recommend that you leave it in the chassis and prepare to replace it within that specified time limit.



Note

If you remove more than one fan tray at a time during operations, the router allows up to 2 minutes before shutting down, unless you replace extra missing fan trays within that time. If the router senses an over temperature condition when multiple fan trays are removed, the shutdown can occur in less than 2 minutes.

Procedure

Step 1 Unscrew the captive thumbscrew at the front of the fan tray.

Figure64:RemoveFanModulefromtheChassis





Figure65:RemoveFanTrayfromtheChassis(N540X-16Z4G8Q2C-A)



Step2 Pullthefantraytoremovethefantraytobereplaced.

Step3 HoldthefanmodulewiththeLEDandPIDlabelatthetop.

Step4

Alignthefanmoduletotheopenfantrayslotinthechassisandpressthemoduleallthewayintotheslotuntiltheleft andrightlatchesclickandlockonthechassis.

Step5

Ifthechassisispoweredon,listenforthefans.Youshouldimmediatelyhearthem inoperation.Ifyou do nothearthem, ensurethatthefanmoduleisinsertedcompletelyinthechassis.

Step6 VerifythatthefanmoduleLED isgreen.IftheLED isnotgreen,oneormorefansarefaulty.

ReplacePowerSupply

The router provides a choice of two different power supplies:

- DC power—The DC power supply uses two-position terminal block-style connector with positive latching or securing, and labeled connections for +24/48V, GRD, -24/48V. The terminal block connector is of

suitable size to carry the appropriate AWG wire size to handle the input current of the power supply. No ON/OFF switch is provided.

- AC power—The AC power supply has an IEC 320-type power receptacle and a 15 Amp service connector.

You can use standard right-angle power cords with the AC power supply. The power supply includes a power cord retainer. No ON/OFF switch is provided.

You can install dual power supplies for redundancy.



Note Products that have an AC power connection are required to have an external SPD provided as part of building installation to comply with the Telcordia GR-1089-NES standard for electromagnetic compatibility and safety.



Caution Do not use interface module and power supply ejector handle to lift the chassis; using the handle can deform or damage the handles.

PSU Redundancy Lost Alarm:

PSU redundancy lost alarms are generated when there is no proper input feed applied on any one of Power Modules (PMs)

(PM0 or PM1). The alarms are also generated when the output for PM0 or PM1 is not proper.



Note This is applicable to fixed PSU only.

The following alarms are raised for PSU redundancy lost event with a fault:

- PM0:
 - Power Module Generic Fault
 - Power Module Error
 - Power Group Redundancy Lost

This is applicable to the following routers with fixed PSUs:

- N540-28Z4C-SYS-A/D
- N540X-16Z4G8Q2C-A/D
- N540X-16Z8Q2C-D
- N540-12Z20G-SYS-A/D
- N540X-12Z16G-SYS-A/D

Remove the DC Power Supply Module

This section provides information about removing and replacing the DC power supply.



Warning **Statement 1003**—DC Power Disconnection

To reduce risk of electric shock or personal injury, disconnect DC power before removing or replacing components or performing upgrades.

Follow these steps to remove and replace the DC power supply:

Procedure

Step 1 Before servicing the power supply, switch off the circuit breaker in your equipment area. As an additional tap the circuit-breakers switch in the Off position.

Step 2 Slip on the ESD-preventive wrist strap that is included in the accessory kit.

Step 3 Switch the power supply circuit-breakers switch to the Off (O) position.

Step 4 Pull the terminal block plug connector out of the terminal block head in the power supply.

(See the following figure.) **Step 5** Loosen the captive screws on the DC power supply.

Step 6

Grasp the power supply handle. Press the power supply lock toward the left and simultaneously pull the power supply

out from the chassis while supporting it with the other hand.

Install the DC Power Supply Module

This equipment is suitable for installation in Network Telecommunications Facilities and locations where the NEC applies.

This equipment is suitable for installations utilizing the Common Bonding Network (CBN).

The grounding architecture of this product is DC-Isolated (DC-I) for DC-powered products. DC-powered products have a nominal operating DC voltage of 48 VDC.

Perform the following procedure to install the power supply module:

Procedure

Step 1 Ensure that the system (earth) ground connection has been made. See the following figure.

Step 2 If necessary, remove the blank power supply filler plate from the chassis power supply bay opening by loosening the captive installation screws.

Step 3


Verify that power to the DC circuit connected to the power supply you are installing is off. To ensure that power has been removed from the DC circuits, locate the circuit breakers for the DC circuits, switch the circuit breaker to the OFF position, and tap the circuit-breakers switches in the OFF position.

Step 4

Grasp the power supply handle with one hand. Place your other hand underneath the power supply. Slide the power supply into the power supply bay. Make sure that the power supply is fully seated in the bay.

Step 5 Tighten the captive installation screws of the power supply. The recommended maximum torque is 5.5 in.-lb (0.62 N-m).

Figure66:InstallDCPowerSupplyModule



RemovetheACPowerSupplyModule

This section describes how to remove and replace the AC power supply.



Warning

Statement1046—Installing or Replacing the Unit

To reduce risk of electric shock, when installing or replacing the unit, the ground connection must always be made first and disconnected last.

If your unit has modules, secure them with the provided screws.



Warning

Statement1074—Comply with Local and National Electrical Codes

To reduce risk of electric shock or fire, installation of the equipment must comply with local and national electrical codes.

Follow these steps to remove and replace the AC power supply:

Procedure

- Step1 Disconnect the power cord from the power source. Do not touch any metal on the power cord when it is still to the power supply.
- Step2 Loosen the tie and remove the power cord from the tie-and holder.
- Step3

Remove the power cord from the power connection on the power supply. Do not touch the metal prong embedded in the power supply.

Step4

Graspthepowersupplyhandle.Pressthepowersupplylocktowardstheleftandsimultaneouslypullthepowersupply outfromthechassiswhilesupportingitwiththeotherhand.

InstalltheACPowerSupplyModule

FollowthesestepstoinstalltheACpowersupplymodule:

Procedure


Step1 Ensurethatthesystem(earth)groundconnectionhasbeenmade.

Step2 Ifnecessary,removetheblankpowersupplyfillerplatefromthechassispowersupplybayopeningbylooseningtheinstallationscrews.

Step3

Graspthepowersupplyhandlewithonehand.Placeyourotherhandunderneaththepowersupply.Slidethepower supplyintothepowersupplybay.Makesurethatthepowersupplyisfullyseatedinthebay.Seethefollowing figure.

Figure67:InstallACPowerSupplyModule



Step4 SlidetheACpowersupplycordinsidethetieofthetie-and-

Step5 holderandtightenthetiearoundthepowersupplycord.

Step6 Pushthepowersupplymoduleintothechassisuntilitlocks.



APPENDIX A

Appendix

Certain troubleshooting aids of the Cisco NCS540 enable you to perform these tasks that assist the troubleshooting process:

- [LEDs, on page 101](#)
- [System Specifications, on page 107](#)

LEDs



Note The Cisco NCS540 Router LEDs are similar for most of the variants, and any differences between are specifically called out.

Router LEDs

All the data port LEDs in the Cisco NCS540 Router are at the front panel. There are 5 LEDs that reflect the different statuses of the system.



Note The following table is applicable only for Cisco N540-24Z8Q2C-SYS, N540X-ACC-variants.

Table 23: Router LED Descriptions

LED	Color	Status
STATUS	Green	The module is operational and has no active major or critical alarms.
	Amber	Host kernel is booted and is ready to start SysAdmin VM.
	Red	Power-unfailure is preventing the CPLD from booting (set by hardware).
	Flashing Amber (Slow)	The module is booting up (set by IO FPGA).
	Flashing Amber (Fast)	The module is booting up (set by BIOS), shutting down, or the SysAdmin VM is being reloaded.
	Flashing Red	RP0 has active major or critical alarms.
	Off	The module is powered-off (set by hardware).
ALARM	Red	Critical alarm-system-scope (including RP0).
	Flashing Red	Critical alarm-Relating to voltage rail failures.
	Amber	Major alarm-system-scope (including RP0).
	Flashing Amber	Minor alarm-system-scope (including RP0).
	Off	No alarm.
SYNC	Green	Time core is synchronized to an external source including IEEE 1588.
	Flashing Green	System is in Synchronous Ethernet mode.
	Amber	Acquiring state or Holdover: Time core is in acquiring state or holdover mode.
	Off	Time core clock synchronization is disabled or in free-running state.
STATUS+ALARM (Both LEDs)	Flashing Red	Secure Boot boot flash contents validation failed. (set by IO FPGA). This case is only applicable immediately after power-on.
TIMING	Off	GPS config and GPS port is down. Time-of-day (ToD), 1PPS, and 10 MHz ports are not provisioned or disabled.
	Amber	ToD, 1PPS, and 10 MHz signals are not valid.
	Green	GPS port is up. ToD, 1PPS, and 10 MHz signals are valid.

LED	Color	Status
GNSS	Off	GNSSisnotconfigured.
	Green	GNSSNormalState.Self-surveyiscomplete.
	Red	Powerup.GNSSisnottrackinganysatellite.
	Amber	Autoholdover.
	FlashingGreen	Learningstate-normal.Self-surveyisnotcompleted.



Note The following table is applicable only for Cisco N540-28Z4C-SYS-A/D, N540-12Z20G-N540X-16Z4G8Q2C-A/D, N540X-16Z8Q2C-D and N540-12Z20G-SYS-A/D variants.

Table 24: Router LED Descriptions

LED	Color	Status
Alarm	Red	Critical alarm-system-scope (including RP0).
	Amber	Major alarm-system-scope (including RP0).
	Flashing Amber	Minor alarm-system-scope (including RP0).
	Off	No alarm.
Status	Green	The module is operational but has no active major or critical alarms.
	Amber	Host kernel booted and XR is booting.
	Flashing Red	Not Applicable.

FanAssemblyLEDs

Cisco NCS540 has 4 fans at the back panel. There is an LED on each fan assembly and they reflect the different status of the fans.



Note The following table is applicable only for Cisco N540-24Z8Q2C-SYS, N540X-16Z8Q2C-and N540-ACC-SYS variants.

Table25:FanAssemblyLEDDescriptions

LED	Color	Status
STATUS	Green	Fansareoperatingnormally.
	Amber	Singlefanfailure.
	Red	MorethanonefanfailureorasinglePSUfanfailure.
	Off	Fantrayisnotreceivingpower.



Note ThefollowingtableisapplicableonlyforCiscoN540-28Z4C-SYS-A/D,N540-12Z20G-N540X-12Z16G-SYS-A/D,andN540X-16Z4G8Q2C-A/Dvariants.

Table26:FanAssemblyLEDDescriptions

LED	Color	Status
FAN	Green	Fansareoperatingnormally.
	Amber	Singlefanfailure.
	Red	MorethanoneorsinglefanfailureorsinglePSUfanfailure(onlyonN540-28Z4C-SYS-A/DandN540-12Z20G-SYS-A/Dvariants)

PowerSupplyLEDs



Note ThefollowingtableisapplicableonlyforCiscoN540-24Z8Q2C-SYS,N540X-16Z8Q2C-andN540-ACC-SYSvariants.

Table27:PowerSupplyLEDDescriptions

POWERLED	FAILED	PowerSupplyCondition
Green	Off	PowerSupplyON;validinput/output.

POWERLED	FAILED	PowerSupplyCondition
Amber1Hz flashing	Red1Hzflashing	PSUWarningdueto: •Overcurrent •Overtemperature •Undervoltage •Overvoltage •Overpower •Fanfailure
Off	On	PSUfailuredueto: •Overcurrent •Overtemperature •Undervoltage •Overvoltage •Overpower •Fanfailure
Green1Hz flashing	Off	Powersupplyisnotpluggedintothechassisorshutdownbythe system
Off	Off	Novalidpowerinput.
Amber	Off	Lowinputvoltage.



Note The following table is applicable only for Cisco N540-28Z4C-SYS-A/D, N540-12Z20G-N540X-12Z16G-SYS-A/D, and N540X-16Z4G8Q2C-A/D variants.

Table28:PowerSupplyLEDDescriptions

LED	Color	Status
PWR	Green	PowerSupplyONandoperatingnormally.
	Off	NotreceivingpowerorPSU-12Vfailor3V3STDBYfailure.
	Red	Powerfailurewithoneoftheinputpowerfeedsfailedoroneofthe on-boardvoltage railshasfailed
	Amber	STDBYFPGAupgradeisinprogressduetopostReload/ Powercycle afterHWFPDupgradeAll. Note UpgradeoftheSTDBYFPGA takes3-5minutes.

FanAssemblyandPowerSupplyLEDCombination



Note ThefollowingtableisapplicableonlyforCiscoN540-28Z4C-SYS-A/D,N540-12Z20G-N540X-12Z16G-SYS-A/D,andN540X-16Z4G8Q2C-A/Dvariants.

Table29:FanAssemblyandPowerSupplyLEDCombinationDescriptions

FanLED	PowerLED	Status
Off	Red	Powerfailurewithoneoftheinputpower feedsfailedoroneoftheon-boardvoltage railshasfailed.
—	Amber	STDBYFPGAupgradeisinprogressdueto postReload/PowercycleafterHWFPD upgradeAll. Note UpgradeoftheSTDBYFPGA takes3-5 minutes
Green	FlashingAmber	Thermalshutdownwithnofan
FlashingRed	FlashingRed	Thermalshutdown
FlashingRed	FlashingAmber	MSSReady=0
FlashingAmber	FlashingGreen	TAMinitfail
FlashingAmber	FlashingRed	TAMNotReady
FlashingAmber	FlashingAmber	SECUREJTAGFail
FlashingGreen	FlashingGreen	BIOSValidationFailure

FanLED	PowerLED	Status
Off	Green	PowerSupplyONandoperatingnormally

System Specifications

Certain troubleshooting aids of the Cisco NCS540 enable you to perform these tasks that assist the troubleshooting process:

Weight and Power Consumption

For information on physical specifications and power consumption, see [table Cisco NCS 540 chassis specification](#) on the [Cisco Network Convergence System 540 Router Data Sheet](#).

Environmental Specifications

For information on environmental specifications, see [table Environmental properties for NCS 540 fixed systems](#) on the [Cisco Network Convergence System 540 Router Data Sheet](#).

Thermal limitations

This [table](#) describes the maximum operating temperature ranges supported for the NCS540 chassis when using specific optics modules, identified by their product IDs (PIDs). It details:

- Optics module: The model of the optics module.
- Chassis PID: The specific chassis or system product ID that supports these optics modules.
- System maximum and minimum operating temperatures supported at MSL: Maximum operating temperatures supported by the NCS540 system at Mean Sea Level (MSL).
- Ports supported: The specific ports on the chassis where the optics modules can be installed.

Table30:Thermallimitations

Opticsmodule	ChassisPID	Maximum operating temperature	Ports supported
SFP-10G-OLT20-X	•N540-24Z8Q2C-SYS •N540-ACC-SYS	•+50C	•P0,P2,P4,P6,P8,P10,P12,P14,P16,P18,P20,P22,P24,P26,P28,P30
	•N540X-16Z4G8Q2C-D •N540X-	•+50C	•P4,P5,P6,P7,P8,P9,P10,P11,P13,P15,P17,P19,P21,P23,P25,P27
	•N540-28Z4C-SYS-D •N540-28Z4C-SYS-A	•+50C	•P0,P1,P2,P3,P5,P7,P9,P11,P13,P15,P17,P19,P21,P23,P25,P27
QSFP-100G-ZR4-S	•N540-28Z4C-SYS-D •N540-28Z4C-SYS-A	•+55C	•P28andP30
DWDM-SFP10G-C-I	•N540X-12Z16G-SYS-A •N540X-12Z16G-SYS-	•+65C	•P20toP27
S10G-LR-PM-D-I	•N540-24Z8Q2C-SYS •N540-28Z4C-SYS-A/D •N540-12Z20G-SYS-A/D •N540X-12Z16G-SYS-A/D •N540X-16Z4G8Q2C-A/D	•+68C •+68C •+68C •+65C •+65C	•Allports(P0-31) •P3toP25 •P20toP31 •P16toP27 •P4toP19
S10G-SR-PM-D-I	•N540-24Z8Q2C-SYS •N540-28Z4C-SYS-A/D •N540X-12Z16G-SYS-A/D •N540-12Z20G-SYS-A/D •N540X-16Z4G8Q2C-A/D	•+69C •+69C •+65C •+69C •+65C	•Allports(P0-31) •P3toP25 •P16toP27 •P20toP31 •P4toP19
S10G-ER-PM-D-I	•N540-24Z8Q2C-SYS •N540-28Z4C-SYS-A/D •N540X-16Z4G8Q2C-A/D •N540X-12Z16G-SYS-A/D	•+60C •+60C •+63C •+60C	•Allports(P0-31) •P3toP25 •P4toP19 •P16toP27

Optics module	Chassis PID	Maximum operating temperature	Ports supported
DP01QS28-E20	• N540X-16Z4G8Q2C-A • N540-24Z8Q2C-M	• +45C	• Two 100GE ports

EMC compliance

This table describes the maximum number of ports supported on various NCS540 medium density router models when using specific optics modules. It details:

- **Optics module:** The model of the optics module.
- **Chassis PID:** The specific chassis or system product ID that supports these optics modules.
- **Maximum number of supported ports:** Refer to the highest number of ports on a chassis that can be supported to meet electromagnetic compatibility (EMC) and electromagnetic interference (EMI) compliance.

Table 31: EMC compliance

Optics module	Chassis PID	Maximum number of supported ports
S10G-LR-PM-D-I	• N540-24Z8Q2C-SYS • N540-28Z4C-SYS-A/D • N540-12Z20G-SYS-A/D • N540X-12Z16G-SYS-A/D • N540X-16Z4G8Q2C-A/D	6
S10G-SR-PM-D-I	• N540-24Z8Q2C-SYS • N540-28Z4C-SYS-A/D • N540X-12Z16G-SYS-A/D • N540-12Z20G-SYS-A/D • N540X-16Z4G8Q2C-A/D	6
S10G-ER-PM-D-I	• N540-24Z8Q2C-SYS • N540-28Z4C-SYS-A/D • N540X-16Z4G8Q2C-A/D • N540X-12Z16G-SYS-A/D	6

Transceiver and Cable Specifications

To determine which transceivers and cables are supported by this router, see [Cisco Transceiver Modules Compatibility Information](#).

To see the transceiver specifications and installation information, see [Cisco Transceiver Modules Install and Upgrade Guides](#).

RJ-45 Connectors

The RJ-45 connector connects Category 3, Category 5, Category 5e, Category 6, or Category 6A foil twisted-pair or unshielded twisted-pair cable from the external network to the following module interface connectors:

- Router chassis
 - CONSOLE port
 - MGMTETH port




Caution

To comply with GR-
(FTP) cable that is properly grounded at both ends.

The following figures show the RJ-45 connector.

Figure 68: RJ-45 Connector



1	Pin1	2	Pin2
---	------	---	------

GPS Port Pinouts

The platform is capable of receiving or sourcing GPS signals of 1PPS & 10MHz. These interfaces are provided by two mini-coax 50-Ohm, 1.0/2.3 DIN series connectors on the front panel. Similarly, there are two mini-coax 50-Ohm connectors provided in the front panel to output this 1PPS and 10MHz.

This table below summarizes the GPS port pinouts:

Table 32: GPS Port Pinouts

	10MHz (Input and Output)	1PPS (Input and Output)
Waveform	Input—Sinewave Output—Squarewave	Input—Rectangular pulse Output—Rectangular pulse

	10MHz(InputandOutput)	1PPS(InputandOutput)
Amplitude	Input—>1.7voltpp(+8to+10dBm) Output—	Input— >2.4voltsTTLcompatible Output—
Impedance	50ohms	50ohms
Pulse Width	50%dutycycle	26microseconds
RiseTime	Input—ACcoupled Output—5nanoseconds	40nanoseconds

Time-of-DayPortPinouts

This table summarizes the ToD/1-PPS port pinouts:

Table 33: RJ-45 ToD/1-PPS Port Pinouts

Pin	Signal Name	Direction	Description
1	-	-	-
2	-	-	-
3	1PPS_N	Output or Input	1PPS RS422 signal
4	GND	-	-
5	GND	-	-
6	1PPS_P	Output or Input	1PPS RS422 signal
7	TOD_N	Output or Input	Time-of-Day character
8	TOD_P	Output or Input	Time-of-Day character

BITS Interface

This table summarizes the BITS interface RJ48 port pinouts:

Table 34: BITS Interface RJ48 Port Pinouts

Pin	Signal Name	Direction	Description
1	RX Ring	Input	Receive Ring
2	RX TIP	Input	Receive TIP (T1/F1)

Pin	Signal Name	Direction	Description
3,6,7,8	—	NC	—
4	TXRing	Output	TransmitRing
5	TXTIP	Output	TransmitTIP (T1/E1)

ManagementandPTPEthernetPortPinouts

This following table summarizes the Management and Precision Time Protocol (PTP) Ethernet port pinouts:

Table 35: Management and PTP Ethernet Port Pinouts

Pin	Signal Name
1	TRP0+
2	TRP0-
3	TRP1+
4	TRP1-
5	TRP2+
6	TRP2-
7	TRP3+
8	TRP3-

USB Port Pinouts

This following table summarizes the USB port pinouts:

Table 36: USB Port Pinouts

Pin	Signal Name	Description
A1	Vcc	+5VDC
A2	D-	Data-
A3	D+	Data+
A4	Gnd	Ground

AlarmPortPinouts

The following table summarizes the external alarm input pinouts for the following NCS540 router variants:

- N540-ACC-SYS
- N540X-ACC-SYS
- N540-24Z8Q2C-SYS
- N540X-16Z8Q2C-D
- N540-28Z4C-SYS

Table 37: External Alarm Input Pinouts

Pin	Signal Name	Description
1	ALARM0_IN	Alarm input 0
2	ALARM1_IN	Alarm input 1
3	—	No connect
4	ALARM2_IN	Alarm input 2
5	ALARM3_IN	Alarm input 3
6	—	No connect
7	—	No connect
8	COMMON	Alarm common

The following table summarizes the external alarm input pinouts for the following NCS540 router variants:

- N540-28Z4C-SYS-A/D
- N540X-16Z4G8Q2C-A/D
- N540-12Z20G-SYS-A/D
- N540X-12Z16G-SYS-A/D

Table 38: External Alarm Input Pinouts

Pin	Signal Name	Description
1	ALARM0_IN	Alarm input 0
2	ALARM1_IN	Alarm input 1
3	—	Alarm output closed
4	ALARM2_IN	Alarm input 2

Pin	SignalName	Description
5	ALARM3_IN	Alarminput3
6	—	Alarmoutputopen
7	—	AlarmoutputCOM
8	—	AlarminputCOM

EffectiveCiscoIOSXRRelease7.3.1,youcanenableexternalalarmsforexternaldoors,voltage,fire,thermal, andwatersensorsonthefollowingvariantsofCiscoNCS540:

- N540-24Z8Q2C-SYS
- N540X-ACC-SYS
- N540-ACC-SYS

To set the description:

```
sysadmin-vm:0_RP0(config)#alarm-contact contact-number description description
```

To set the severity of the alarm:

```
sysadmin-vm:0_RP0(config)#alarm-contact contact-number severity [critical | major | minor]
```

EffectiveCiscoIOSXRRelease7.4.1,youcanenableexternalalarmsforexternaldoors,voltage,fire,thermal, andwatersensorsonthefollowingvariantsofCiscoNCS540:

- N540-28Z4C-SYS-A/D
- N540-12Z20G-SYS-A/D
- N540X-16Z4G8Q2C-A/D
- N540X-12Z16G-SYS-A/D

To set the description:

```
RP/0/RP0/CPU0:ios(config)#environmental-alarm-contact contact-number description description
```

To set the severity of the alarm:

```
RP/0/RP0/CPU0:ios(config)#environmental-alarm-contact contact-number severity [critical | major | minor]
```

To set the trigger for the alarm:

```
RP/0/RP0/CPU0:ios(config)#environmental-alarm-contact contact-number trigger [open | closed]
```



Note You can configure up to four external alarms.

The *contact-number* is the pin number of the connected alarm port, that is Alarminput0 to Alarminput3.

The **description** string can be up to 80 alphanumeric characters in length and is included in a system-generated message.

For **severity**, enter any one of: **critical**, **major**, or **minor**.

Description and severity are both mandatory values.

Use the **show alarms** command in admin mode to view the alarm details. Use the **show logging** command to view the display state of syslog error and event logging.

An SNMP trap is sent for every external alarm that is raised or cleared on the system.

ConsolePortPinouts

The following table summarizes the Console port pinouts.



Note The following table is applicable only for Cisco N540-24Z8Q2C-SYS, N540X-ACC-variants.

Table 39: ConsolePortPinouts

Pin	SignalName	Direction	Description
1	Loop1	NA	Loopback1
2	Loop2	NA	Loopback2
3	TxD	Output	Console RS232 transmit
4	Gnd	NA	Ground
5	Gnd	NA	Ground
6	RxD	Input	Console RS232 receive
7	Loop2	NA	Loopback2
8	Loop1	NA	Loopback1



Note The following table is applicable only for Cisco N540-28Z4C-SYS-A/D, N540-12Z20G-N540X-12Z16G-SYS-A/D, and N540X-16Z4G8Q2C-A/D variants.

Table 40: ConsolePortPinouts

Pin	SignalName	Direction	Description
1	ACONS-TX	Output	Aux Console transmit output, RS232
2	NC	NA	Receive TIP (T1/E1)

Pin	SignalName	Direction	Description
3	CONS-TX	Output	ConsoleRS232transmit
4	Gnd	NA	Ground
5	Gnd	NA	Ground
6	CONS-RX	Input	ConsoleRS232receive
7	ACONS-RTX	Input	AuxConsolesreceiveinput,RS 232
8	NC	NA	NA